aiwa

aiwa SERVICE

CX-N5100
CX-N5200
CX-N5250
SX-N5200

SERVICE MANUAL



COMPACT DISC STEREO SYSTEM

- BASIC TAPE MECHANISM : 2ZM – 3 PR1
- BASIC CD MECHANISM : KSM – 2101ABM
- TYPE U

[REVISION PUBLISHING]

1260

S/M Code No. 09 – 945 – 054 – 50T

TABLE OF CONTENTS

SPECIFICATIONS 3
PROTECTION OF EYES FROM LASER BEAM DURING SERVICING 4
PRECAUTION TO REPLACE OPTICAL BLOCK (KSS – 210A) 4
ELECTRICAL MAIN PARTS LIST ..... 5~10
TRANSISTOR ILLUSTRATION 10
BLOCK DIAGRAM – 1 (MAIN/FRONT) ..... 11~12
BLOCK DIAGRAM – 2 (CD) ..... 13~14
BLOCK DIAGRAM – 3 (TUNER) 15
BLOCK DIAGRAM – 4 (ECHO/DSP) 16
WIRING – 1 (MAIN) ..... 17~18
SCHEMATIC DIAGRAM – 1 (MAIN) ..... 19~20
WIRING – 2 (FRONT) ..... 21~22
SCHEMATIC DIAGRAM – 2 (FRONT) ..... 23~24
WIRING – 3 (CD) ..... 25~26
SCHEMATIC DIAGRAM – 3 (CD) ..... 27~28
WIRING – 4 (ECHO/DSP) ..... 29~30
SCHEMATIC DIAGRAM – 4 (ECHO/DSP) 31
IC DESCRIPTION ..... 32~37
IC BLOCK DIAGRAM ..... 38~41
FL GRID ASSIGNMENT/ANODE CONNECTION 42
ELECTRICAL ADJUSTMENT ..... 43~48
PRACTICAL SERVICE FIGURE 45
SPRING APPLICATION POSITION 49
MECHANICAL EXPLODED VIEW 1/2 50
MECHANICAL PARTS LIST 1/2 51
MECHANICAL EXPLODED VIEW 2/2 52
MECHANICAL PARTS LIST 2/2 53
CD MECHANISM EXPLODED VIEW 1/1 54
CD MECHANISM PARTS LIST 1/1 54
TAPE MECHANISM EXPLODED VIEW 1/1 ..... 55~56
TAPE MECHANISM PARTS LIST 1/1 57
SPEAKER PARTS LIST 58
ACCESSORIES/PACKAGE LIST 59
REFERENCE NAME LIST 60

SPECIFICATIONS

TUNER/AMPLIFIER

<FM section>

Frequency range	87.5 MHz to 108 MHz
Usable sensitivity (IHF)	1.3 µV (75 ohms) 13.2 dBf
Alternate channel selectivity	50 dB (±400 kHz)
Signal-to-noise ratio	STEREO: 70 dB MONO: 76 dB
Harmonic distortion	0.3 % (MONO), 1 kHz 0.5 % (STEREO, L-R), 1 kHz
Frequency response	30 Hz to 15 kHz (+0.5 dB, – 3 dB)
Stereo separation	33 dB at 1 kHz
Antenna	75 ohms (unbalanced)

<AM section>

Frequency range	AM 530 (531) kHz to 1710 (1602) kHz
Usable sensitivity	350 µV/m
Selectivity	22 dB (9 kHz)
Signal-to-noise ratio	53 dB (100 dB input)
Antenna	Loop antenna

<Timer section>

Program timer	On-timer, free setting
Sleep timer	Setting in 10-minute increments, 240 minutes maximum

<Amplifier section>

Power output	FTC RULE 40 watts per channel, Min. RMS at 6 ohms, from 65 Hz to 15 kHz, with no more than 1 % Total Harmonic Distortion
Harmonic distortion	0.05 % (15 W, 1 kHz, 6 ohms)
Input terminal	VIDEO/AUX: 150 mV (adjustable) MIC: 1.8 mV/10 kΩ
Output terminal	SUPER WOOFER: 1.55 V

CASSETTE DECK/COMPACT DISC PLAYER

<Cassette deck section>

Track format	4 tracks, 2 channels
Frequency response	CrO_2 tape: 50 – 16000 Hz Normal tape: 50 – 15000 Hz
Signal-to-noise ratio	60 dB (DOLBY NR ON, CrO_2 tape peak level)
Tape speed	4.8 cm/sec. (1 7/8 ips)
Recording system	AC bias
Erasure system	AC erase
Motor	DC servo motor × 1
Heads	Playback head × 1 (deck 1) Recording/playback/erasure head × 1 (deck 2)

<CD player section>

Disc	Compact disc
Scanning method	Non-contact optical scanner (semi-conductor laser)
Laser	Semiconductor laser (λ = 780 nm)
Rotation speed	Approx. 500 rpm – 200 rpm (CLV)
Error correction	Cross Interleave, Reed Solomon code
No. of channels	2 channels
D-A conversion	16-bit linear
Wow/flutter	Unmeasurable
Signal-to-noise ratio	90 dB (1 kHz, 0 dB)
Harmonic distortion	0.05% (1 kHz, 0 dB)

SPEAKER SYSTEM

(These values are for one speaker.)

Cabinet type	3 way, bass reflex (magnetism sealed type)
Speaker	130 mm (5 1/8 in.) cone type woofer 50 mm (2 in.) cone type tweeter 20 mm (13/16 in.) ceramic type super tweeter
Impedance	6 ohms
Music power	50 W
Output sound pressure level	88 dB/W/m
Dimensions (W × H × D)	180 × 302 × 230 mm (7 1/8 × 12 × 9 1/8 in.)
Weight	2.8 kg (6.2 lbs.)

COMMON SECTION

Power requirements	NSX-5100/NSX-5200: AC 120 V, 60 Hz NSX-5250: AC 120 V/220–240 V, switchable 60 Hz
Power consumption (System total)	105 W
Dimensions (W × H × D)	Main unit: 260 × 305 × 340 mm (10 1/4 × 12 1/8 × 13 1/2 in.) System: 620 × 305 × 340 mm (24 1/2 × 12 1/8 × 13 1/2 in.)
Weight	Main unit: 7.6 kg (16.7 lbs.) System: 13.2 kg (29 lbs.)

- Design and specifications are subject to change without notice.
- Dolby noise reduction manufactured under license from Dolby Laboratories Licensing Corporation.
  "DOLBY" and the double-D symbol ⧈ are trademarks of Dolby Laboratories Licensing Corporation.
- The word "BBE" and the "BBE symbol" are trademarks of BBE Sound, Inc.
  Under license from BBE Sound, Inc.

PROTECTION OF EYES FROM LASER BEAM DURING SERVICING

This set employs laser. Therefore, be sure to follow carefully the instructions below when servicing.

WARNING!!
WHEN SERVICING, DO NOT APPROACH THE LASER EXIT WITH THE EYE TOO CLOSELY. IN CASE IT IS NECESSARY TO CONFIRM LASER BEAM EMISSION. BE SURE TO OBSERVE FROM A DISTANCE OF MORE THAN 30cm FROM THE SURFACE OF THE OBJECTIVE LENS ON THE OPTICAL PICK-UP BLOCK.



- Caution: Invisible laser radiation when open and interlocks defeated avoid exposure to beam.
- Advarsel: Usynlig laserståling ved åbning, når sikkerhedsafbrydere er ude af funktion. Undgå udsættelse for stråling.

VAROITUS!
Laiteen Käyttäminen muulla kuin tässä käyttöohjeessa mainitulla tavalla saattaa altistaa käyt-täjän turvallisuusluokan 1 ylittävälle näkymättömälle lasersäteilylle.

VARNING!
Om apparaten används på annat sätt än vad som specificeras i denna bruksanvising, kan användaren utsättas för osynling laserstrålning, som överskrider gränsen för laserklass 1.

CAUTION
Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

ATTENTION
L'utilisation de commandes, réglages ou procédures autres que ceux spécifiés peut entraîner une dangereuse exposition aux radiations.

ADVARSEL!
Usynlig laserståling ved åbning, når sikkerhedsafbrydereer ude af funktion. Undgå udsættelse for stråling.

This Compact Disc player is classified as a CLASS 1 LASER product.
The CLASS 1 LASER PRODUCT label is located on the rear exterior.

CLASS 1	LASER PRODUCT
KLASSE 1	LASER PRODUKT
LUOKAN 1	LASER LAITE
KLASS 1	LASER APPARAT

Precaution to replace Optical block (KSS – 210A)

Body or clothes electrostatic potential could ruin laser diode in the optical block. Be sure to ground body and workbench, and use care the clothes do not touch the diode.

1) After the connection, remove the solder shown in the right figure.



ELECTRICAL MAIN PARTS LIST

DESCRIPTIONで判断できない物は "REFERENCE NAME LIST" を参照してください。
If can't understand for Description please kindly refer to "REFERENCE NAME LIST".

REF. NO	PART NO.	カンリ NO.	DESCRIPTION
IC			
	87-017-745-010		IC, CXA1782BQ
	87-020-454-010		IC, DM6851
	87-017-486-080		IC, BA6397FP
	87-017-586-010		IC, CXD 2518Q
⚠	87-001-196-080		IC, ICP-N10
	87-017-194-010		IC, PLT104
	83-NF5-646-010		IC, LC866432V-5506
	87-017-585-080		IC, NJM4580E
	87-017-373-010		IC, NJH32H380A
	87-001-582-010		IC, STK4152-2
	87-017-738-010		IC, NJM2068LD
	87-001-982-010		IC, TA7291S
	87-017-674-010		IC, XR1090
	87-002-727-010		IC, NJM4558L
	87-017-375-080		IC, TC4094BF
	87-001-874-010		IC, HA12134A
	87-017-673-010		IC, BA3837
	87-017-449-010		IC, XR-1071CP〈5100〉
	87-001-607-080		IC, NJM4558M
	87-017-374-010		IC, TC4094BP
	87-002-247-010		IC, BU4052B
	87-017-448-010		IC, GD4052B
	87-002-272-080		IC, TC4052 BF
	87-001-376-010		IC, LC7218
	87-017-714-010		IC, LA1836
	87-002-872-080		IC, MC14053 BF
	87-017-309-010		IC, M65830P
TRANSISTOR			
	89-110-154-080		TR, 2SA1015Y
	87-026-463-080		TR, 2SA933S(RS)
	89-113-187-080		TR, 2SA1318TU
	87-026-233-080		C-TR, DTA114TK
	87-026-211-080		C-TR, DTA144EK T147
	89-213-702-010		TR, 2SB1370E
	87-026-609-080		TR, KTA1266GR
	87-026-610-080		TR, KTC3198GR
	89-327-125-080		C-TR, 2SC2712GR
	89-332-665-080		TR, 2SC3266GR
	89-111-625-080		C-TR, 2SA1162GR
	89-333-266-080		C-TR, 2SC3326B
	87-026-232-080		C-TR, DTA144WK
	87-026-210-080		C-TR, DTC144EK T147
	89-213-293-080		TR, 2SB1329R
	89-318-154-080		TR, 2SC1815Y
	89-333-317-080		TR, 2SC3331T
	87-026-213-080		C-TR, DTC114YK
	87-026-226-080		C-TR, DTA143EK
	89-503-655-680		FET, 2SK365GR, BL
	87-026-224-080		C-TR, DTC143XK
	89-109-521-080		TR, 2SA952K
	89-112-965-080		TR, 2SA1296GR
	89-406-555-080		TR, 2SD655E
	89-502-464-080		FET, 2SK246Y
	87-026-214-080		TR, DTA114YS
	89-327-143-080		C-TR, 2SC2714 (O)
	89-503-025-080		C-FET, 2SK302 GR
	89-505-434-580		C-FET, 2SK543(4/5)
DIODE			
	87-002-564-080		DIODE, 1SS133 RA
	87-017-447-010		DIODE, GBU4DL
	87-002-608-080		DIODE, DSF10TC
	87-017-011-080		DIODE, LT IN4003L
	87-020-691-080		DIODE, 1SS132 T-72
	87-020-027-080		C-DIODE, 1SS184
	87-020-125-080		C-DIODE, 1SS181
	87-020-465-080		DIODE, ISS133
	87-017-174-080		ZENER, HZS11A3L
	87-017-147-080		ZENER, HZS33-2
	87-001-731-080		ZENER, HZS6C2L
	87-017-091-080		ZENER, HZS5C1
	87-020-331-080		C-DIODE, DAN202K
	87-001-290-080		ZENER, HZS6B1L
	87-020-330-080		C-DIODE, DAP202K
	87-001-559-080		DIODE, ISS131(T-72)
	87-017-083-080		ZENER, HZS4C2
MAIN C.B			
C101	87-016-055-090		CAP, E 3300-42 HI-R
C102	87-016-055-090		CAP, E 3300-42 HI-R
C103	87-010-390-090		CAP, E 3300-25 SME
C104	87-010-235-080		CAP, E 470-16 SME
C105	87-010-381-080		CAP, E 330-16 SME
C106	87-010-430-080		CAP, E 100-63
C107	87-010-260-080		CAP, E 47/25 SME
C108	87-010-382-080		CAP, E 22-25 SME
C109	87-010-263-080		CAP, E 100-10
C112	87-010-237-080		CAP, E 1000-16
C113	87-010-403-080		CAP, E 3.3-50 SME
C115	87-016-247-080		C-CAP, 0.1-50 F
C116	87-012-140-080		C-CAP, S 470P-50 CH
C118	87-016-247-080		C-CAP, 0.1-50 F
C119	87-018-205-080		CAP, TC-U 0.022-25 F
C120	87-018-205-080		CAP, TC-U 0.022-25 F
C121	87-018-209-080		CAP, TC-U 0.1-50 F
C152	87-010-374-080		CAP, E 47-10
C213	87-010-404-080		CAP, E 4.7-50 SME
C214	87-010-404-080		CAP, E 4.7-50 SME
C215	87-010-182-080		C-CAP, S 2200P-50 B
C216	87-010-182-080		C-CAP, S 2200P-50 B
C217	87-010-404-080		CAP, E 4.7-50 SME
C218	87-010-404-080		CAP, E 4.7-50 SME
C219	87-010-185-080		C-CAP, S 3900P-50 B
C220	87-010-185-080		C-CAP, S 3900P-50 B
C221	87-010-545-080		CAP, E 0.22-50 SME
C222	87-010-545-080		CAP, E 0.22-50 SME
C223	87-010-260-080		CAP, E 47-25 SME
C224	87-010-260-080		CAP, E 47-25 SME
C225	87-010-260-080		CAP, E 47-25 SME
C226	87-010-260-080		CAP, E 47-25 SME
C227	87-012-368-080		C-CAP, S 0.1-50F
C228	87-012-368-080		C-CAP, S 0.1-50F
C229	87-012-361-080		C-CAP, S 0.056-25 Y
C230	87-012-361-080		C-CAP, S 0.056-25 Y
C236	87-010-408-080		CAP, E 47-50 SME
C243	87-010-154-080		C-CAP, S 10P-50 CH
C244	87-010-154-080		C-CAP, S 10P-50 CH
C245	87-010-194-080		C-CAP, S 0.047-25 F
C250	87-010-196-080		C-CAP, S 0.1-25 F
C303	87-012-155-080		C-CAP, S 180P-50 CH
C304	87-012-155-080		C-CAP, S 180P-50 CH
C305	87-010-189-080		C-CAP, S 8200P-50 B
C306	87-010-189-080		C-CAP, S 8200P-50 B
C309	87-010-197-080		C-CAP, S 0.01-25 B
C310	87-010-197-080		C-CAP, S 0.01-25 B
C311	87-010-213-080		C-CAP, S 0.015-25 B
C312	87-010-213-080		C-CAP, S 0.015-25 B
C313	87-010-197-080		C-CAP, S 0.1-25 B
C351	87-012-154-080		C-CAP, S 150P-50 CH
C352	87-012-154-080		C-CAP, S 150P-50 CH
C353	87-012-145-080		C-CAP, S 270P-50 CH
C354	87-012-145-080		C-CAP, S 270P-50 CH
C355	87-012-154-080		C-CAP, S 150P-50 CH

REF. NO	PART NO.	カンリ NO.	DESCRIPTION
C356	87-012-154-080		C-CAP, S 150P-50 CH
C357	87-010-189-080		C-CAP, S 8200P-50 B
C358	87-010-189-080		C-CAP, S 8200P-50 B
C361	87-010-197-080		C-CAP, S 0.01-25 B
C362	87-010-197-080		C-CAP, S 0.01-25 B
C363	87-010-197-080		C-CAP, S 0.01-25 B
C364	87-010-197-080		C-CAP, S 0.01-25 B
C401	87-010-402-080		CAP, E 2.2-50 SME
C402	87-010-402-080		CAP, E 2.2-50 SME
C405	87-010-197-080		C-CAP, S 0.01-25 B
C406	87-010-197-080		C-CAP, S 0.01-25 B
C409	87-010-181-080		C-CAP, S 1800P-50 B
C410	87-010-181-080		C-CAP, S 1800P-50 B
C411	87-010-188-080		C-CAP, S 6800P-50 B
C412	87-010-188-080		C-CAP, S 6800P-50 B
C415	87-012-154-080		C-CAP, S 150P-50 CH
C416	87-012-154-080		C-CAP, S 150P-50 CH
C451	87-012-156-080		C-CAP, S 220P-50 CH
C452	87-012-156-080		C-CAP, S 220P-50 CH
C453	87-010-178-080		C-CAP, S 1000P-50 B
C456	87-010-260-080		CAP, E 47-25 SME
C457	87-010-197-080		C-CAP, S 0.01-25 B
C458	87-010-183-080		C-CAP, S 2700P-50 B
C459	87-010-183-080		C-CAP, S 2700P-50 B
C460	87-010-183-080		C-CAP, S 2700P-50 B
C470	87-010-196-080		C-CAP, S 0.1-25 F
C501	87-010-196-080		C-CAP, S 0.1-25 F
C502	87-010-196-080		C-CAP, S 0.1-25 F
C503	87-012-155-080		C-CAP, S 180P-50 CH
C504	87-012-155-080		C-CAP, S 180P-50 CH
C507	87-010-178-080		C-CAP, S 1000P-50 B
C508	87-010-178-080		C-CAP, S 1000P-50 B
C509	87-010-371-080		CAP, E 470-6.3
C515	87-010-545-080		CAP, E 0.22-50 SME
C516	87-010-545-080		CAP, E 0.22-50 SME
C517	87-012-142-080		C-CAP, S 0.33-16 F
C518	87-012-142-080		C-CAP, S 0.33-16 F
C519	87-010-196-080		C-CAP, S 0.1-25 F
C521	87-010-197-080		C-CAP, S 0.01-25 B
C522	87-010-318-080		C-CAP, S 47P-50 CH
C523	87-010-197-080		C-CAP, S 0.01-25 B
C524	87-010-402-080		CAP, E 2.2-50 SME
C530	87-010-194-080		C-CAP, S 0.047-25 F
C531	87-010-545-080		CAP, E 0.22-50 SME
C532	87-010-382-080		CAP, E 22-25 SME
C533	87-010-404-080		CAP, E 4.7-50 SME
C534	87-010-404-080		CAP, E 4.7-50 SME
C535	87-010-404-080		CAP, E 4.7-50 SME
C536	87-010-404-080		CAP, E 4.7-50 SME
C537	87-010-196-080		C-CAP, S 0.1-25 F
C538	87-010-196-080		C-CAP, S 0.1-25 F
C539	87-010-405-080		CAP, E 10-50 SME
C540	87-010-260-080		CAP, E 47-25 SME
C541	87-010-196-080		C-CAP, S 0.1-25 F
C543	87-010-546-080		CAP, E 0.33-50 SME
C544	87-010-546-080		CAP, E 0.33-50 SME
C545	87-010-400-080		CAP, E 0.47-50 SME
C546	87-010-400-080		CAP, E 0.47-50 SME
C547	87-012-365-080		C-CAP, S 0.027-25 BK
C548	87-012-365-080		C-CAP, S 0.027-25 BK
C549	87-012-142-080		C-CAP, S 0.33-16 F
C550	87-016-081-080		C-CAP, S 0.1-16 RK
C551	87-016-081-080		C-CAP, S 0.1-16 RK
C601	87-010-401-080		CAP, E 1-50 SME〈5100〉
C602	87-010-405-080		CAP, E 10-50 SME〈5100〉
C603	87-010-101-080		CAP, E 220-16 SME〈5100〉
C605	87-015-627-080		C-CAP, 1000P-50 B K〈5100〉
C606	87-015-627-080		C-CAP, 1000P-50 B K〈5100〉
C607	87-010-404-080		CAP, E 4.7-50 SME〈5100〉
C608	87-010-404-080		CAP, E 4.7-50 SME〈5100〉

REF. NO	PART NO.	カンリ NO.	DESCRIPTION
C609	87-010-404-080		CAP, E 4.7-50 SME〈5100〉
C610	87-010-404-080		CAP, E 4.7-50 SME〈5100〉
C611	87-010-177-080		C-CAP, S 820P-50 SL〈5100〉
C612	87-010-177-080		C-CAP, S 820P-50 SL〈5100〉
C613	87-010-404-080		CAP, E 4.7-50 SME〈5100〉
C614	87-010-404-080		CAP, E 4.7-50 SME〈5100〉
C615	87-010-400-080		CAP, E 0.47-50 SME〈5100〉
C616	87-010-400-080		CAP, E 0.47-50 SME〈5100〉
C617	87-010-197-080		C-CAP, S 0.01-25 B〈5100〉
C618	87-010-197-080		C-CAP, S 0.01-25 B〈5100〉
C619	87-010-184-080		C-CAP, S 3300P-50 B〈5100〉
C620	87-010-184-080		C-CAP, S 3300P-50 B〈5100〉
C621	87-012-155-080		C-CAP, S 180P-50 CH〈5100〉
C622	87-012-155-080		C-CAP, S 180P-50 CH〈5100〉
C623	87-010-405-080		CAP, E 10-50 SME〈5100〉
C624	87-010-405-080		CAP, E 10-50 SME〈5100〉
C630	87-010-405-080		CAP, E 10-50 SME〈5100〉
C631	87-010-401-080		CAP, E 1-50 SME〈5100〉
C640	87-010-196-080		C-CAP, S 0.1-25 F
C641	87-010-196-080		C-CAP, S 0.1-25 F
C645	87-012-142-080		C-CAP, S 0.33-16 F
C646	87-012-142-080		C-CAP, S 0.33-16 F
C647	87-012-142-080		C-CAP, S 0.33-16 F
C648	87-012-142-080		C-CAP, S 0.33-16 F
C701	87-010-381-080		CAP, E 330-16 SME
C702	87-010-404-080		CAP, E 4.7-50 SME
C703	87-010-197-080		C-CAP, S 0.01-25 B
C704	87-010-197-080		C-CAP, S 0.01-25 B
C711	87-010-263-080		CAP, E 100-10
C712	87-010-196-080		C-CAP, S 0.1-25 F
C722	87-010-312-080		C-CAP, S 15P-50 CH
C723	87-010-178-080		C-CAP, S 1000P-50 B
C724	87-010-178-080		C-CAP, S 1000P-50 B
C725	87-010-178-080		C-CAP, S 1000P-50 B
C726	87-010-178-080		C-CAP, S 1000P-50 B
C727	87-010-194-080		C-CAP, S 0.047-25 F
C728	87-010-248-080		CAP, E 220-10 SME
C732	87-010-197-080		C-CAP, S 0.01-25 B
C771	87-010-405-080		CAP, E 10-50 SME
C772	87-010-194-080		C-CAP, S 0.047-25 F
C773	87-010-196-080		C-CAP, S 0.1-25 F
C774	87-010-263-080		CAP, E 100-10
C775	87-010-405-080		CAP, E 10-50 SME
C776	87-010-197-080		C-CAP, S 0.01-25 B
C777	87-010-400-080		CAP, E 0.47-50 SME
C778	87-010-401-080		CAP, E 1-50 SME
C779	87-010-401-080		CAP, E 1-50 SME
C780	87-010-197-080		C-CAP, S 0.01-25 B
C781	87-010-405-080		CAP, E 10-50 SME
C782	87-010-405-080		CAP, E 10-50 SME
C787	87-010-184-080		C-CAP, S 3300P-50 B
C788	87-010-184-080		C-CAP, S 3300P-50 B
C789	87-010-179-080		C-CAP, S 1200P-50 B
C790	87-010-179-080		C-CAP, S 1200P-50 B
C791	87-010-401-080		CAP, E 1-50 SME
C792	87-010-180-080		C-CAP, S 1500P-50 B
C793	87-010-189-080		C-CAP, S 8200P-50 B
C794	87-010-408-080		CAP, E 47-50 SME
C795	87-010-194-080		C-CAP, S 0.047-25 F
C796	87-010-403-080		CAP, E 3.3-50 SME
C797	87-010-405-080		CAP, E 10-50 SME
C798	87-010-196-080		C-CAP, S 0.1-25 F
C802	87-010-154-080		C-CAP, S 10P-50 CH
C804	87-010-151-080		C-CAP, S 7P-50 CH
C805	87-010-150-080		C-CAP, S 6P-50 CH
C806	87-010-145-080		C-CAP, S 1P-50 CH
C807	87-010-154-080		C-CAP, S 10P-50 CH
C808	87-010-322-080		C-CAP, S 100P-50 CH
C809	87-010-197-080		C-CAP, S 0.01-25 B
C810	87-010-197-080		C-CAP, S 0.01-25 B

REF. NO	PART NO.	カンリ NO.	DESCRIPTION
C811	87-010-149-080		C-CAP, S 5P-50 CH
C812	87-010-313-080		C-CAP, S 18P-50 CH
C813	87-010-197-080		C-CAP, S 0.01-25 B
C814	87-010-197-080		C-CAP, S 0.01-25 B
C816	87-010-197-080		C-CAP, S 0.01-25 B
C817	87-010-197-080		C-CAP, S 0.01-25 B
C818	87-010-197-080		C-CAP, S 0.01-25 B
C819	87-010-197-080		C-CAP, S 0.01-25 B
C820	87-010-260-080		CAP, E 47-25 SME
C821	87-010-197-080		C-CAP, S 0.01-25 B
C822	87-015-819-080		CHIP CAP 0.01
C823	87-010-197-080		C-CAP, S 0.01-25 B
C830	87-010-197-080		C-CAP, S 0.01-25 B
C831	87-010-154-080		C-CAP, S 10P-50 CH
C835	87-010-154-080		C-CAP, S 10P-50 CH
C836	87-010-312-080		C-CAP, S 15P-50 CH
C837	87-010-312-080		C-CAP, S 15P-50 CH
C840	87-010-197-080		C-CAP, S 0.01-25 B
C843	87-010-146-080		C-CAP, S 2P-50 CH
C944	87-010-311-080		C-CAP, S 12P-50 CH
C946	87-010-401-080		CAP, E 1-50 SME
C947	87-010-197-080		C-CAP, S 0.01-25 B
C948	87-010-401-080		CAP, E 1-50 SME
C950	87-010-322-080		C-CAP, S 100P-50 CH
C981	87-018-134-080		CAP, TC-U 0.01-16 Y
C983	87-010-544-080		CAP, E 0.1-50
C984	87-010-196-080		C-CAP, S 0.1-25 F
C985	87-010-196-080		C-CAP, S 0.1-25 F
C987	87-010-197-080		C-CAP, S 0.01-25 B
C988	87-010-196-080		C-CAP, S 0.1-25 F
C990	87-010-197-080		C-CAP, S 0.01-25 B
CF801	87-008-261-010		FLTR, SFE10.7MA5-A
CF802	87-008-261-010		FLTR, SFE10.7MA5-A
D801	87-002-730-080		VARI-CAP SVC203SPA
D802	87-002-730-080		VARI-CAP SVC203SPA
D803	87-002-730-080		VARI-CAP SVC203SPA
J250	87-049-855-010		JACK, 6.3 W/S
J253	87-099-475-010		JACK, PIN 3P BLK W/E
J254	87-033-226-010		TERMINAL, SP 4P (JT)
J652	80-MT3-616-010		JACK, PIN 2P
J801	82-NF5-621-010		ANT TERM JBT 0222
L401	87-003-131-080		COIL, 10MH J
L402	87-003-131-080		COIL, 10MH J
L403	87-005-525-080		COIL, 22MH-J
L404	87-005-525-080		COIL, 22MH-J
L451	82-NV3-610-010		COIL, OSC BIAS 85K
L701	81-631-643-010		COIL, 1 POLE MPX
L702	81-631-643-010		COIL, 1 POLE MPX
L741	87-006-253-010		COIL, FM DET N
L742	81-NT1-659-010		FLTR, CFAZ-450 2NT
L770	87-003-102-080		COIL, 10UH
L771	87-003-098-080		COIL, 2.2UH
L801	87-006-249-010		COIL, ANT FM3/4TS, L4
L802	87-006-254-010		COIL, ANT FM2-3/4TS, S
L803	87-006-244-010		COIL, RF FM 3-1/2T, L4
L804	87-006-250-010		COIL, RF FM 3-1/2TS, L4
L805	87-003-098-080		COIL, 2.2UH
L806	87-008-427-010		COIL, FMIFT (4T)
L807	87-006-205-010		COIL, OSC FM (7K)
L832	87-003-098-080		COIL, 2.2UH
L981	82-NT3-632-010		AM PACK 1, SAG
R105	87-022-050-080		RES, METAL 1W-0.22J
R106	87-022-050-080		RES, METAL 1W-0.22J
RY101	87-045-361-010		RELAY, DH12D2-OS(M)-2
SFR301	87-024-349-080		SFR, 1K DIA6 H
SFR302	87-024-349-080		SFR, 1K DIA6 H
SFR351	87-024-349-080		SFR, 1K DIA6 H
SFR352	87-024-349-080		SFR, 1K DIA6 H
SFR401	87-024-349-080		SFR, 1K DIA6 H
SFR402	87-024-349-080		SFR, 1K DIA6 H

REF. NO	PART NO.	カンリ NO.	DESCRIPTION
SFR451	87-024-356-080		SFR, 47K DIA6 H
SFR452	87-024-356-080		SFR, 47K DIA6 H
SFR722	87-024-171-080		SFR, 4.7K DIA6 V
SFR771	87-024-173-080		SFR, 22K DIA6 V
TC701	87-011-221-080		TRIMER 30P VCT51
TC801	87-011-219-080		CAP TRIMMER 10P VCT
TC802	87-011-219-080		CAP TRIMMER 10P VCT
VR651	83-NF5-639-010		VR, 50KBX2 RK14K12A0
W101	81-MX4-647-010		F-CABEL, 7P-2.5
X703	84-508-618-010		VIB, CER CSB 456 F/5
X721	87-030-163-010		VIB, XTAL 7.2MHZ(NDK)

FRONT C.B

C201	87-010-404-040		CAP, E 4.7-50 SME
C202	87-010-404-040		CAP, E 4.7-50 SME
C203	87-010-408-040		CAP, E 47-50 SME
C204	87-010-401-040		CAP, E 1-50 SME
C205	87-010-263-040		CAP, E 100-10
C206	87-010-248-040		CAP, E 220-10
C207	87-010-401-040		CAP, E 1-50 SME
C208	87-010-805-080		C-CAP, S 1-16 F
C210	87-010-146-080		C-CAP, S 2P-50 CH
C212	87-010-405-040		CAP, E 10-50 SME
C213	87-010-196-080		C-CAP, S 0.1-25 F
C214	87-010-196-080		C-CAP, S 0.1-25 F
C215	87-010-196-080		C-CAP, S 0.1-25 F
C242	87-012-140-080		C-CAP, S 470P-50 CH
C352	87-010-197-080		C-CAP, S 0.01-25 B
C381	87-010-196-080		C-CAP, S 0.1-25 F
C382	87-010-196-080		C-CAP, S 0.1-25 F
C383	87-010-196-080		C-CAP, S 0.1-25 F
C389	87-010-150-080		C-CAP, S 6P-50 CH
C401	87-010-196-080		C-CAP, S 0.1-25 F
C501	87-010-384-040		CAP, E 100-25 SME
C604	87-010-183-080		C-CAP, S 2700P-50 B
C606	87-010-401-040		CAP, E 1-50 SME
C607	87-012-140-080		C-CAP, S 470P-50 CH
C608	87-010-405-040		CAP, E 10-50 SME
C609	87-010-196-080		C-CAP, S 0.1-25 F
C610	87-012-145-080		C-CAP, S 270P-50CH
C613	87-010-805-080		C-CAP, S 1-16 F
C624	87-010-183-080		C-CAP, S 2700P-50 B
C626	87-010-401-040		CAP, E 1-50 SME
C627	87-012-140-080		C-CAP, S 470P-50 CH
C630	87-010-405-040		CAP, E 10-50 SME
C640	87-010-405-040		CAP, E 10-50 SME
C645	87-010-263-040		CAP, E 100-10
C646	87-010-196-080		C-CAP, S 0.1-25 F
C650	87-010-260-040		CAP, E 47-25 SME
C701	87-010-175-080		C-CAP, S 560P-50 SL
C702	87-010-175-080		C-CAP, S 560P-50 SL
C703	87-010-154-080		C-CAP, S 10P-50 CH
C704	87-010-154-080		C-CAP, S 10P-50 CH
C705	87-012-154-080		C-CAP, S 150P-50 CH
C706	87-012-154-080		C-CAP, S 150P-50 CH
C707	87-010-220-080		C-CAP, S 0.018-25 B
C708	87-010-220-080		C-CAP, S 0.018-25 B
C709	87-010-186-080		C-CAP, S 4700P-50 B
C710	87-010-186-080		C-CAP, S 4700P-50 B
C711	87-012-140-080		C-CAP, S 470P-50 CH
C712	87-012-140-080		C-CAP, S 470P-50 CH
C713	87-010-213-080		C-CAP, S 0.015-25 B
C714	87-010-213-080		C-CAP, S 0.015-25 B
C715	87-010-318-080		C-CAP, S 47P-50 CH
C716	87-010-318-080		C-CAP, S 47P-50 CH
C717	87-010-178-080		C-CAP, S 1000P-50 B
C718	87-010-178-080		C-CAP, S 1000P-50 B
C719	87-010-176-080		C-CAP, S 680P-50 SL

REF. NO	PART NO.	カンリ NO.	DESCRIPTION
C720	87-010-176-080		C-CAP, S 680P-50 SL
C721	87-010-402-040		CAP, E 2.2-50 SME
C722	87-010-402-040		CAP, E 2.2-50 SME
C729	87-010-263-040		CAP, E 100-10
C730	87-010-384-040		CAP, E 100-25 SME
FL101	83-NF5-630-010		FIL, BJ238GK
FT101	83-NF5-632-010		CABLE FFC, 6P-1.25
FT102	82-NF5-651-010		CABLE FFC, 14P-1.25
J601	82-NF7-630-010		JACK, 3.5 MO
J621	82-NF7-630-010		JACK, 3.5 MO
L349	87-003-149-080		COIL, 47UH
LED401	87-017-784-080		LED, SEL1550CM TP8
LED402	87-017-784-080		LED, SEL1550CM TP8
LED403	87-017-784-080		LED, SEL1550CM TP8
LED404	87-017-784-080		LED, SEL1550CM TP8
LED405	87-017-784-080		LED, SEL1550CM TP8
LED406	87-017-784-080		LED, SEL1550CM TP8
LED407	87-017-731-080		LED, SEL1510CM2
LED408	87-017-731-080		LED, SEL1510CM2
LED409	87-017-785-080		LED, SEL4214S
LED410	87-017-731-080		LED, SEL1510CM2
LED411	87-017-731-080		LED, SEL1510CM2
LED412	87-017-731-080		LED, SEL1510CM2
LED413	87-017-731-080		LED, SEL1510CM2
LED414	87-017-731-080		LED, SEL1510CM2
LED420	87-017-785-080		LED, SEL4214S
LED421	87-017-731-080		LED, SEL1510CM2
LED422	87-017-785-080		LED, SEL4214S
LED423	87-017-785-080		LED, SEL4214S
S301	87-036-215-080		SW, TACT EVQ21404M
S302	87-036-215-080		SW, TACT EVQ21404M
S303	87-036-215-080		SW, TACT EVQ21404M
S304	87-036-215-080		SW, TACT EVQ21404M
S305	87-036-215-080		SW, TACT EVQ21404M
S306	87-036-215-080		SW, TACT EVQ21404M
S307	87-036-215-080		SW, TACT EVQ21404M
S308	87-036-215-080		SW, TACT EVQ21404M
S321	87-036-215-080		SW, TACT EVQ21404M
S322	87-036-215-080		SW, TACT EVQ21404M
S323	87-036-215-080		SW, TACT EVQ21404M
S324	87-036-215-080		SW, TACT EVQ21404M
S325	87-036-215-080		SW, TACT EVQ21404M
S326	87-036-215-080		SW, TACT EVQ21404M
S327	87-036-215-080		SW, TACT EVQ21404M
S328	87-036-215-080		SW, TACT EVQ21404M
S329	87-036-215-080		SW, TACT EVQ21404M
S330	87-036-215-080		SW, TACT EVQ21404M
S331	87-036-215-080		SW, TACT EVQ21404M
S332	87-036-215-080		SW, TACT EVQ21404M
S341	87-036-215-080		SW, TACT EVQ21404M
S342	87-036-215-080		SW, TACT EVQ21404M
S343	87-036-215-080		SW, TACT EVQ21404M
S344	87-036-215-080		SW, TACT EVQ21404M
S345	87-036-215-080		SW, TACT EVQ21404M
S346	87-036-215-080		SW, TACT EVQ21404M
S347	87-036-215-080		SW, TACT EVQ21404M
S348	87-036-215-080		SW, TACT EVQ21404M〈5100〉
VR601	82-NK7-616-010		VR, 10KB RK11K1130
VR602	82-NK7-615-010		VR, 10KA RK11K1130
X201	87-030-345-080		VIB, CER CST 5.76MGW

3CD C.B

REF. NO	PART NO.	カンリ NO.	DESCRIPTION
C1	87-010-188-080		C-CAP, S 6800P-50 B
C2	87-010-196-080		C-CAP, S 0.1-25 F
C3	87-010-196-080		C-CAP, S 0.1-25 F
C4	87-010-196-080		C-CAP, S 0.1-25 F
C5	87-010-404-080		CAP, E 4.7-50 SME
C6	87-010-213-080		C-CAP, S 0.015-25 B
C7	87-010-197-080		C-CAP, S 0.01-25 B
C8	87-010-403-080		CAP, E 3.3-50 SME
C9	87-010-382-080		CAP, E 22-25 SME
C10	87-010-260-080		CAP, E 47-25 SME
C11	87-010-197-080		C-CAP, S 0.01-25 B
C12	87-010-193-080		C-CAP, S 0.033-25 F
C13	87-010-197-080		C-CAP, S 0.01-25 B
C14	87-010-193-080		C-CAP, S 0.033-25 F
C15	87-010-182-080		C-CAP, S 2200P-50 B
C21	87-010-198-080		C-CAP, S 0.022-25 B
C22	87-010-196-080		C-CAP, S 0.1-25 F
C23	87-010-263-080		CAP, E 100-10
C24	87-010-178-080		C-CAP, S 1000P-50 B
C25	87-010-197-080		C-CAP, S 0.01-25 B
C26	87-010-260-080		CAP, E 47-25 SME
C27	87-010-196-080		C-CAP, S 0.1-25 F
C28	87-010-263-080		CAP, E 100-10
C29	87-010-197-080		C-CAP, S 0.01-25 B
C30	87-010-196-080		C-CAP, S 0.1-25 F
C31	87-010-193-080		C-CAP, S 0.033-25 F
C33	87-010-196-080		C-CAP, S 0.1-25 F
C34	87-010-197-080		C-CAP, S 0.01-25 B
C35	87-010-381-080		CAP, E 330-16 SME
C36	87-010-196-080		C-CAP, S 0.1-25 F
C37	87-010-260-080		CAP, E 47-25 SME
C38	87-010-197-080		C-CAP, S 0.01-25 B
C39	87-010-260-080		CAP, E 47-25 SME
C40	87-010-197-080		C-CAP, S 0.01-25 B
C41	87-010-146-080		C-CAP, S 2P-50 CH
C42	87-010-154-080		C-CAP, S 10P-50 CH
C45	87-010-196-080		C-CAP, S 0.1-25 F
C101	87-010-194-080		C-CAP, S 0.047-25 F
C102	87-010-180-080		C-CAP, S 1500P-50 B
C103	87-010-263-080		CAP, E 100-10
C104	87-010-197-080		C-CAP, S 0.01-25 B
C105	87-010-186-080		C-CAP, S 4700P-50 B
C106	87-012-156-080		C-CAP, S 220P-50 CH
C107	87-010-197-080		C-CAP, S 0.01-25 B
C108	87-010-400-080		CAP, E 0.47-50 SME
C112	87-010-154-080		C-CAP, S 10P-50 CH
C113	87-010-154-080		C-CAP, S 10P-50 CH
C114	87-010-314-080		C-CAP, S 22P-50 CH
C115	87-010-404-080		CAP, E 4.7-50 SME
C116	87-010-263-080		CAP, E 100-10
C117	87-010-194-080		C-CAP, S 0.047-25 F
C118	87-010-154-080		C-CAP, S 10P-50 CH
C120	87-010-263-080		CAP, E 100-10
C121	87-010-197-080		C-CAP, S 0.01-25 B
C122	87-010-196-080		C-CAP, S 0.1-25 F
C201	87-012-153-080		C-CAP, S 120P-50 CH
C202	87-012-153-080		C-CAP, S 120P-50 CH
C203	87-012-153-080		C-CAP, S 120P-50 CH
C204	87-012-153-080		C-CAP, S 120P-50 CH
C205	87-012-153-080		C-CAP, S 120P-50 CH
C206	87-012-153-080		C-CAP, S 120P-50 CH
C207	87-012-153-080		C-CAP, S 120P-50 CH
C208	87-012-153-080		C-CAP, S 120P-50 CH
C209	87-012-153-080		C-CAP, S 120P-50 CH
C210	87-012-153-080		C-CAP, S 120P-50 CH
C211	87-010-401-080		CAP, E 1-50 SME
C212	87-010-401-080		CAP, E 1-50 SME
C213	87-010-186-080		C-CAP, S 4700P-50 B
C214	87-010-186-080		C-CAP, S 4700P-50 B
C231	87-010-263-080		CAP, E 100-10
C232	87-010-263-080		CAP, E 100-10
C301	87-010-178-080		C-CAP, S 1000P-50 B
C304	87-010-197-080		C-CAP, S 0.01-25 B
C305	87-010-260-080		CAP, E 47-25 SME
C306	87-010-198-080		C-CAP, S 0.022-25 B
C307	87-010-178-080		C-CAP, S 1000P-50 B
C308	87-010-178-080		C-CAP, S 1000P-50 B

REF. NO	PART NO.	カンリ NO.	DESCRIPTION
L1	87-003-295-080		COIL, 10UH
M301	87-045-305-010		MOTOR, RF-500TB
SFR1	87-024-176-080		SFR, 100K DIA6 V
SFR2	87-024-173-080		SFR 22K DIA6 V
SFR3	87-024-176-080		SFR, 100K DIA6 V
W301	83-NF5-631-010		F-CABLE, 6-2.0 300
W501	83-NF5-644-010		F-CABLE, 2-2.0-230
X101	87-030-227-080		VIB, XTAL 33.8688MHZ

ECHO/DSP C.B

C901	87-010-248-040		CAP, E 220-10 SME
C902	87-010-384-040		CAP, E 100-25 SME
C903	87-010-186-080		C-CAP, S 4700P-50 B
C904	87-010-322-080		C-CAP, S 100P-50 CH
C905	87-010-401-040		CAP, E 1-50 SME
C906	87-010-187-080		C-CAP, S 5600P-50 B
C907	87-010-193-080		C-CAP, S 0.033-25 F
C908	87-010-544-040		CAP, E 0.1-50 SME
C909	87-010-188-080		C-CAP, S 6800P-50 B
C910	87-012-365-080		C-CAP, S 0.027-25V BK
C911	87-010-263-040		CAP, E 100-10
C912	87-010-196-080		C-CAP, S 0.1-25 F
C913	87-010-316-080		C-CAP, S 33P-50 CH
C914	87-010-177-080		C-CAP, S 820P-50 SL
C915	87-010-316-080		C-CAP, S 33P-50 CH
C916	87-010-177-080		C-CAP, S 820P-50 SL
C917	87-010-179-080		C-CAP, S 1200P-50 B
C918	87-010-196-080		C-CAP, S 0.1-25 F
C919	87-010-260-040		CAP, E 47-25 SME
C920	87-010-400-040		CAP, E 0.47-50
C921	87-010-400-040		CAP, E 0.47-50
C922	87-010-196-080		C-CAP, S 0.1-25 F
C923	87-010-187-080		C-CAP, S 5600P-50 B
C924	87-010-179-080		C-CAP, S 1200P-50 B
C925	87-010-198-080		C-CAP, S 0.022-25 B
C926	87-010-196-080		C-CAP, S 0.1-25 F
C927	87-010-181-080		C-CAP, S 1800P-50 B
C928	87-010-181-080		C-CAP, S 1800P-50 B
C929	87-010-382-040		CAP, E 22-25 SME
C941	87-010-197-080		C-CAP, S 0.01-25 B
C942	87-010-197-080		C-CAP, S 0.01-25 B
C960	87-010-260-040		CAP, E 47-25 SME
L901	87-005-490-080		COIL, 270UH J FLR50

MVR C.B

C735	87-010-402-040		CAP, E 2.2-50 SME
C736	87-010-402-040		CAP, E 2.2-50 SME
C738	87-010-370-040		CAP, E 330-6.3 SME
C741	87-010-192-080		C-CAP, S 0.022-50 F
C745	87-016-073-080		CAP, E 1-50 FX
C746	87-016-073-080		CAP, E 1-50 FX
C747	87-010-401-040		CAP, E 1-50 SME
C748	87-010-401-040		CAP, E 1-50 SME
C750	87-010-384-040		CAP, E 100-25 SME
C751	87-010-401-040		CAP, E 1-50 SME
C752	87-010-401-040		CAP, E 1-50 SME
C757	87-010-401-040		CAP, E 1-50 SME
C773	87-010-400-040		CAP, E 0.47-50 SME
C777	87-010-403-040		CAP, E 3.3-50 SME
C778	87-010-403-040		CAP, E 3.3-50 SME
C797	87-010-401-040		CAP, E 1-50 SME
MVR741	81-MT3-630-010		VOL, 50KBX2 (M)

KEY C.B

C351	87-010-197-080		C-CAP, S 0.01-25 B
LED415	87-002-787-080		LED, SEL 6215S RED
LED416	87-002-787-080		LED, SEL 6215S RED
LED417	87-002-787-080		LED, SEL 6215S RED
S349	87-036-215-080		SW, TACT EVQ21404M
S350	87-036-215-080		SW, TACT EVQ21404M
S351	87-036-215-080		SW, TACT EVQ21404M
S352	87-036-215-080		SW, TACT EVQ21404M
S353	87-036-215-080		SW, TACT EVQ21404M

SNSR C.B

PH401	87-026-573-010		P-SNSR, GP1S53V

MOTOR-1 C.B

M302	87-045-305-010		MOTOR, RF-500TB

U/D SW C.B

SW601	87-036-271-010		SW, LVR 1-2-2 (*)

OPEN SW C.B

SW602	87-036-271-010		SW, LVR 1-2-2 (*)

CLOSE SW C.B

SW701	87-036-109-010		SW, PUSH SPPB 61

LED C.B

LED902	87-017-806-010		LED, SEL1810DM
LED902	87-017-806-010		LED, SEL1810DM
LED903	87-017-350-080		LED, SEL1550CM
LED903	87-017-350-080		LED, SEL1550CM
LED904	87-017-350-080		LED, SEL1550CM
LED904	87-017-350-080		LED, SEL1550CM
LED905	87-017-806-010		LED, SEL1810DM
LED905	87-017-806-010		LED, SEL1810DM

MOTOR-2 C.B

M2	9X-262-513-210		SLED MOTOR
S4	91-572-085-110		LEAF SW

AC2 C.B

⚠PT1	83-NF5-606-010		PT, 3NF-5 HE
R101	87-022-537-080		RES, NF 0.68-1/2W J
R102	87-022-537-080		RES, NF 0.68-1/2W J

DECK-1 C.B

SOL1	82-ZM1-618-310		SOL ASSY, 27
SW4	87-036-110-010		SW, PUSH SPPB 62
SW5	87-036-110-010		SW, PUSH SPPB 62
SW6	87-036-110-010		SW, PUSH SPPB 62

DECK-2 C.B

SFR1	87-024-170-080		SFR, 3.3K DIA6 V
SOL2	82-ZM1-618-310		SOL ASSY, 27
SW2	87-036-110-010		SW, PUSH SPPB 62
SW3	87-036-110-010		SW, PUSH SPPB 62
SW4	87-036-110-010		SW, PUSH SPPB 62
SW5	87-036-110-010		SW, PUSH SPPB 62
SW6	87-036-110-010		SW, PUSH SPPB 62

RELAY-1 C.B

REF. NO	PART NO.	ｶﾝﾘ NO.	DESCRIPTION

RELAY-2 C. B

AC1 C. B

⚠	87-033-147-010	CLAMP, FUSE〈5250〉
⚠	82-304-743-010	TERMINAL, 1P
⚠F101	87-035-415-010	FUSE, T2. 5A 250V UL〈5250〉
⚠SW101	87-036-235-010	SW, SLIDE ESD269〈5250〉

○ チップ抵抗部品コード／CHIP RESISTOR PART CODE

チップ抵抗部品コードの成り立ち
Chip Resistor Part Coding



チップ抵抗
Chip resistor

Wattage 容量	Type 種類	Tolerance 許容誤差	Symbol 記号	Dimensions／寸法 (mm) Form/外形	L	W	t	Resistor Code : A 抵抗コード : A
1/32W	1608	±5%	CJ		1.6	0.8	0.35	108
1/10W	2125	±5%	CJ		2	1.25	1.45	118
1/8W	3126	±5%	CJ		3.2	1.6	0.5 ~0.7	128

TRANSISTOR ILLUSTRATION

2SA952 2SC3266
2SA1015 2SC3331
2SA1296 2SD655
2SA1318 KTA1266
2SC1815 KTC3198

2SK246



2SA933S
DTA114YS



2SK365



2SB1329R



2SA1162 DTA144EK
2SC2712 DTA144WK
2SC2714 DTC114YK
2SC3326 DTC143XK
DTA114TK DTC144EK
DTA143EK



2SK302



2SK543



2SB1370

BLOCK DIAGRAM – 1 (MAIN/FRONT)



BLOCK DIAGRAM – 2 (CD)




TUNER BLOCK (U)
AM LOOP
J801
ANTENNA
IF FM 75Ω
AM TRACKING ADJ.
L981
AM PACK1
(1/3)
(2/3)
(3/3)
ANT
OSC
IC770 LA1836
TP4
TP3
S-CURVE
REG
AM LO
AM RF
AM FRONTEND
FM/AM: IF/DET
L742
AM IF ADJ.
X703 456KHz
L701
L702
BUFFERS
MIX CCO
AM IFT
AM IF IN
VCO
LO
LI
RI
RO
FM IF IN
FM/AM
IF BO
FM DET
AM SD ADJ.
AM LBO
TUNE
AM IFO
L OUT
R OUT
STEREO
FUNC.A
TO MAIN BLOCK
Q961
RF BUFF.
CF802 (10.7MHZ)
CF801 (10.7MHZ)
Q805
FM IF AMP
L741
+B
DC BALANCE ADJ.
SFR771
VCO ADJ.
SFR722
AUTO STOP LEVEL ADJ.
TP2
TP7
Q771, 772 TU+B SWITCH
+VM
L802
Ð801
TC801
L801
Q808
RF AMP
L803
FM TRACKING ADJ.
L804
TC802
Ð802
Q802
MIX
L806
FM IF
Q806
FM BAND SW
AMI
FM2
MUTE
ST
MODE
CLK
DI
PLL CE
T-BASE
DO
FM I
EO
L807
Q803
FM OSC
Q804
FM OSC BUFF.
Q701·Q702
PLL L.P.F.
VT
TP1 (VT)
Ð803
FM VT ADJ.
IC720 LC7218 PLL
XO
XI
X721 7.2MHz
TC701
TC701 30P
CLOCK ADJ.
TUNE/IFC
PLLCE
MDATA
CLK
T-BASE
TO MAIN BLOCK


D ECHO/DSP C.B
R IN
L IN
MIC-IN
PIN901
IC901 NJM4558 SURROUND AMP
2/2
1/2
SURROUND BUFFER
IC902 (2/2)
FILTER CONTROL
IC902 (1/2) MC14053BF FILTER CONTROL
IC905 NJM4558M SURROUND AMP
L OUT
R OUT
IC904 M65830P DIGITAL DELAY
AMP
MOD
DEM
DIGITAL DELAY
COMP
LPF
OSC
DELAY CONT
DATA
CLK
REQ
OSC CONT Q901, Q902
IC903 MC14053BF DELAY SELECTOR
ECHO OUT
IC906 TC4094BF
MODE<+>
DSP
QS
ECHO
REV-OFF
OSC-L
STB
DATA
CLK
M-DATA
DSP-CE
M-CLOCK
PIN901


A MAIN C.B
FROM Q RELAY-1 C.B
CON301
TO PIN301
FROM R RELAY-2 C.B
CON351
TO PIN351
J801 ANTENNA
AM LOOP
FM 75Ω
VR651 VIDEO/AUX INPUT LEVEL
J652 VIDEO /AUX
R
L
FROM C 3C6 C.B CN301
W301 RED BRN BRN
TO N AC2 C.B WH102
W101 7 BLK 5 3 BLK 1 YEL
J253 SURROUND SPEAKERS SPEAKER IMP:16Ω
SUPER WOOFFER
J254 SPEAKERS SPEAKER IMP:6Ω
WH601
WH101
RY101
(BLK)
5100 ONLY
5300 ONLY
5200, 5250 ONLY
S AC1 C.B
AC 120V 60Hz
R100
5100, 5200 ONLY
AC 120/220~240V 50/60Hz
F101
SW101
PT1
R101
SW101 AC VOLTAGE 120V 220V 240V
5250 ONLY
N AC2 C.B
R101
R102
WH102
W101 BLK BLK YEL
TO A MAIN C.B WH101
PIN101
PIN102
PIN103
FROM B FRONT C.B
CON601
CON602
CON603
J250 PHONES
PIN351
PIN301
IC770
IC351
IC401
IC604
IC603
IC602
IC605
IC601
IC211
Q112
Q101
Q104
Q106
Q108
Q107
Q206
Q207
Q352
Q451
Q452
Q401
Q402
Q301
Q302
Q303
Q405
Q701
Q702
Q772
Q771
Q806
Q804
Q803
Q801
Q802
Q771
Q772
Q773
Q774
Q775
Q776
Q777
Q778
Q779
Q781
Q782
Q783
Q784
Q785
Q786
Q787
Q788
Q789
Q790
Q791
Q792
Q793
Q794
Q795
Q796
Q797
Q798
Q799
Q800
Q805
Q807
Q808
Q809
Q810
Q811
Q812
Q813
Q814
Q815
Q816
Q817
Q818
Q819
Q820
Q821
Q822
Q823
Q824
Q825
Q826
Q827
Q828
Q829
Q830
Q831
Q832
Q833
Q834
Q835
Q836
Q837
Q838
Q839
Q840
Q841
Q842
Q843
Q844
Q845
Q846
Q847
Q848
Q849
Q850
Q851
Q852
Q853
Q854
Q855
Q856
Q857
Q858
Q859
Q860
Q861
Q862
Q863
Q864
Q865
Q866
Q867
Q868
Q869
Q870
Q871
Q872
Q873
Q874
Q875
Q876
Q877
Q878
Q879
Q880
Q881
Q882
Q883
Q884
Q885
Q886
Q887
Q888
Q889
Q890
Q891
Q892
Q893
Q894
Q895
Q896
Q897
Q898
Q899
Q900
Q901
Q902
Q903
Q904
Q905
Q906
Q907
Q908
Q909
Q910
Q911
Q912
Q913
Q914
Q915
Q916
Q917
Q918
Q919
Q920
Q921
Q922
Q923
Q924
Q925
Q926
Q927
Q928
Q929
Q930
Q931
Q932
Q933
Q934
Q935
Q936
Q937
Q938
Q939
Q940
Q941
Q942
Q943
Q944
Q945
Q946
Q947
Q948
Q949
Q950
Q951
Q952
Q953
Q954
Q955
Q956
Q957
Q958
Q959
Q960
Q961
Q962
Q963
Q964
Q965
Q966
Q967
Q968
Q969
Q970
Q971
Q972
Q973
Q974
Q975
Q976
Q977
Q978
Q979
Q980
Q981
Q982
Q983
Q984
Q985
Q986
Q987
Q988
Q989
Q990
Q991
Q992
Q993
Q994
Q995
Q996
Q997
Q998
Q999
Q1000

SCHEMATIC DIAGRAM – 1 (MAIN)




E MVR C.B
MVR741
VOLUME
MAX ⟷ MIN
F KEY C.B
LED417 S351
LED416 S350
LED415 S349
DISC DIRECT PLAY
S352
DISC CHANGE
S353
OPEN/CLOSE
TO O DECK-1 C.B
TO P DECK-2 C.B
PIN501
PIN502
CON501
CON502
FL101
DISPLAY
FT101
B FRONT C.B
FT102
FROM C 3CB C.B CN302
Q321
POWER
STANDBY/ON
IC380
IC201
IC202
IC203
IC401
IC402
IC403
IC701
IC702
S321
S322
S323
S324
S325
S326
S327
S328
S329
S330
S331
S332
S345
S346
S347
S348
S5100 ONLY
DSP/GEQ
T-BASS
HALL
LIVE
DISCO
CLASSIC
POP
ROCK
TIMER
UP
DOWN
DIRECTION/PRESET
CLEAR
SET
REC MUTE
HIGH
NORMAL
SYNCHRO DUBBING
DEMO
CD EDIT/ REMAIN
REV MODE
DOLBY NR
MIC ECHO OFF/ON
VOCAL FADER MULTIPLEX
VR602
MIC MIXING
VR601
DIGITAL ECHO
J601
MIC2
J621
MIC1
CD
VIDEO/AUX
BAND TUNER
DECK1/2 TAPE
REMOTE SENSOR
CON601
CON602
CON660
PIN101
PIN102
PIN103
FROM A MAIN C.B
TO CON660
PIN901
FROM D ECHO/DSP C.B

SCHEMATIC DIAGRAM – 2 (FRONT)



M MOTOR-2 C.B

M2 (SLED MOTOR)

M3 (SPINDLE MOTOR)

SW1 (INSIDE LIMIT SW)

H MOTOR-1 C.B

M302 (TURN TABLE MOTOR)

G SNSR C.B

I U/D SW C.B

SW601 (UP/DOWN SW)

J OPEN SW C.B

SW602 (OPEN SW)

K CLOSE SW C.B

SW701 (CLOSE SW)

FROM B FRONT C.B CON104

M301 (TRAY LOADING MOTOR)

TO A MAIN C.B WH501

C 3CD C.B

PICK UP ASSY KSS-210A

IC102 CD DIGITAL OUT (OPTICAL) (TO DAT)

L LED C.B

LED902~905 (CD TRAY LIGHTING)


C 3CD C.B
IC101
CX82518Q
DIGITAL SIGNAL PROSCESSOR
IC1
CXA1782BQ
RF SIGNAL
SERVO
PROCESSOR
IC2
MOTOR/COIL
DRIVER
IC2
BA6397FP
IC102
DIGITAL OUT
(OPTIONAL)
TO BAT
IC301 TA7291S
MOTOR DRIVER
TRAY LOADING
CLOSE:3.7
OTHERS:0
M301 RF-500TB
(TRAY LOADING MOTOR)
Q301~303
7VREG/SWITCH
Q301
2SB1329R
Q303
2SC1815Y
Q302
2SB1329R
Q304~307
2SC3331
Q304~
309
TURN
TABLE
DRIVE
MOTOR
Q308, 309
DTC114YK
Q1
2SA1015Y
LD DRIVER
Q2
2SA1318TU
+5V REG.
Q3
DTA114TK
FOK
SW
Q4
DTA144
EK
SW
Q501
DTC143XK
LED SW
IC201
EQ AMP
IC201 (1/2)
NJM 4580 E
IC201 (2/2)
NJM 4580 E
PICKUP ASSY
KSS-210A
MECHANISM
KSM-2101ABM
LD MON
FOCUS
COIL
TRACKING COIL
YR1
SFR1
TRACKING
GAIN ADJ.
SFR2
FOCUS
BIAS ADJ.
SFR3
TRACKING
BALANCE
ADJ.
SFR1
100K
SFR2
22k
SFR3
100K
TP1
(RF OUT)
TP2
(VREF)
TP3
(TE)
TP
(R-IN)
TP
(R-OUT)
L1 10uH
CN1
CN2
CN3
PN1
PN2
PN3
PN301
PN302
PN303
CN401
CN402
CN403
PH401 GP1S53V
M302 (TURN TABLE MOTOR)
H MOTOR-1 C.B
M3 (SPINDLE MOTOR)
M2(SLED MOTOR)
MOTOR-2 C.B
SW
(INSIDE LIMIT SW)
UP/DOWN SW
I U/D SW C.B
CLOSE SW
K CLOSE SW C.B
(CLOSE SW)
SW602
(OPEN SW)
J OPEN SW C.B
SNSR
G SNSR C.B
CN302
FT1102
FROM
B FRONT C.B
CON104
CN501
CN901
W301
W501
W502
TO
A MAIN C.B
WH501
LED902, 905
SEL1810BM
LED903, 904
SEL1550CM
LED902~905
(CD TRAY LIGHTING)
L LED C.B
SUGNAL MARK
AUDIO
D-CLK
D-XLT
D-DATA
I-SENS
D-CD·LED
D-SOCLK
I-SQDATA
I-SW
D-CLOSE
D-OPEN
D-DISH FWD
D-DISH RVS
I-DISH SENS
NC
VM
B-GND
CD-ON
R CH
A-GND
L CH
33.8688MHz

Đ ECHO/ĐSP C.B



O ĐECK-1 C.B

P ĐECK-2 C.B



R RELAY-2 C.B Q RELAY-1 C.B



SCHEMATIC DIAGRAM – 4 (ECHO/DSP)



IC DESCRIPTION

LC866432V – 5506

Pin No.	Pin Name	I/O	Description
1	O-PLL CE	O	PLL IC chip enable.
2	O-KC/CE	O	Key control IC M65840 data latched strobe output.
3	O-M/STB	O	Main shift register (IC602, 603) data latch strobe output.
4	O-M/DATA	O	Main shift register (IC602, 603), PLL/key control/DSP related data output.
5	O-M/CLK	O	Main shift register (IC602, 603), PLL/key control/DSP related clock output.
6	I-$\overline{\text{HOLD}}$	I	Power failure detected input. L to stop clock and maintain memory.
7	$\overline{\text{RESET}}$	I	Reset input.
8	I-$\overline{\text{STEREO}}$	I	Tuner stereo detected input.
9	I-$\overline{\text{TUNE/IFC}}$	I	Tuner $\overline{\text{SD}}$ detected input. IF count serial data input.
10	VSS1	—	GND.
11, 12	CF1, 2	—	5.76MHz oscillator circuit.
13	VDD1	—	Power supply input.
14~16	I-KEY1~3	I	Key input. (A/D)
17	I-CD/SW	I	CD mechanical switch A/D converter input.
18	I-CD/DISH	I	CD turntable photo sensor A/D converter input.
19	I-MS	I	Deck music sensor signal input.
20	I-SPEANA	I	A/D input for spectrum analyzer display.
21	I-MIC	I	Microphone input for auto VF display.
22	I-TM BASE	I	Reference clock input for timer watch.
23	I-CD/SENSE	I	CD IC control SENS input.
24	I-$\overline{\text{RMC}}$	I	System remote control signal input.
25~36	G12~G1	O	FL grid output G12~G1.
37	P22	O	FL segment output P22.
38	P21/O-SPEANA A	O	FL segment output P21, spectrum analyzer band switch output (A).
39	P20/O-SPEANA B	O	FL segment output P20, spectrum analyzer band switch output (B).
40	P19/O-SPEANA C	O	FL segment output P19, spectrum analyzer band switch output (C).
41	VDD2	—	Power supply input.
42	-VP	—	Power supply input (-34.5V) for FL display.
43	P18/CST1	I/O	FL segment output P18, DECK1 cassette detect switch data input.
44	P17/AUTO1	I/O	FL segment output P17, DECK1 auto stop signal input.
45	P16/CAM1	I/O	FL segment output P16, DECK1 cam switch data input.
46	P15/CSM2	I/O	FL segment output P15, DECK2 cam switch data input.
47	P14/AUTO2	I/O	FL segment output P14, DECK2 auto stop data input.
48	P13/CST2	I/O	FL segment output P13, DECK2 cassette detect switch data input.
49	P12/REA2	I/O	FL segment output P12, DECK2 side-A record OK switch data input.
50	P11/REB2	I/O	FL segment output P11, DECK2 side-B record OK switch data input.
51	P10/FM-WIDE	I/O	FL segment output P10, FM wide mode data input to diode.
52	P1/AM-ST	I/O	FL segment output P1, AM stereo mode data input to diode.
53	P2/AM10K	I/O	FL segment output P2, AM 10kHz step data input to diode.

Pin No.	Pin Name	I/O	Description
54	P3/LW	I/O	FL segment output P3, LW mode data input to diode.
55	P4/SW	I/O	FL segment output P4, SW mode data input to diode.
56	P5/BBE	I/O	FL segment output P5, BBE mode data input to diode.
57	P6/DSP	I/O	FL segment output P6, DSP data input to diode.
58	P7/K-CON	I/O	FL segment output P7, key control data input to diode.
59	P8/CDG	I/O	FL segment output P8, CDG data input to diode.
60	P9/OIRT	O	FL segment output P9.
61	O-CLOSE	O	CD tray close data output.
62	O-OPEN	O	CD tray open data output.
63	O-DI/R	O	CD turntable reverse rotation output.
64	O-DI/F	O	CD turntable forward rotation output.
65	O-$\overline{\text{POWER}}$	O	System power supply $\overline{\text{ON}}$/OFF output.
66	O-$\overline{\text{SOL1}}$	O	DECK1 solenoid output.
67	O-$\overline{\text{SOL2}}$	O	DECK2 solenoid output.
68	O-$\overline{\text{MOTOR}}$	O	DECK motor output.
69	O-$\overline{\text{KEY. SCAN}}$	O	Switch scan timing output.
70	O-F/STB	O	Front shift register (IC401~403), data latch strobe output.
71	O-F/CLK	O	Front shift register (IC401~403), data transfer clock output.
72	O-F/DATA	O	Front shift register (IC401~403), data output.
73	VSS2	—	GND.
74	O-DSP/CE	O	DSP related data latch strobe output.
75	O-CD/DATA	O	CD IC control data output.
76	O-CD/XLT	O	CD IC control data latch output.
77	O-CD/CLK	O	CD IC control data transfer clock output.
78	I-CD/SQ. DATA	O	CD SUB-Q data input.
79	O-CD/SQ. CLK	O	Clock output for CD SUB-Q input data.
80	O-MUTE	O	System mute output.

CXD2518Q

Pin No.	Pin Name	I/O	Description
1	SCOR	O	1H when the subcode sync S0 or S1 is detected.
2	SBSO	O	SUBP~W serial output.
3	EXCK	I	Clock input for SBSO read out.
4	SQSO	O	SUBQ 80-bit serial output.
5	SQCK	I	Clock input for SQSO read out.
6	MUTE	I	H to mute. L to cancel. Connected to GND.
7	SENS	O	SENS signal output to CPU (IC201).
8	XRST	I	System reset. L to reset.
9	DATA	I	Serial data input from CPU (IC201).
10	XLAT	I	Latch input from CPU (IC201). Latching serial data at fall down.
11	CLOK	I	Clock input from CPU (IC201) to transfer serial data.
12	VSS	—	GND.
13	SEIN	I	SENS input from SSP (CXA1782BQ).
14	CNIN	I	Numbers of track jump are counted and input.
15	DATO	O	Serial data output to SSP (CXA1782BQ).
16	XLTO	O	Serial data latched output to SSP (CXA1782BQ). Latched at fall down edge.
17	CLKO	O	Clock input from SSP (CXA1782BQ) to transfer serial data.
18	TEST2	I	TEST. (Connected to +5V)
19~21	SPOB~D	I	Input from INSIDE LIMIT switch (SW1).
22	XLON	O	LC7870E mute control output.
23	FOK	I	Focus OK input pin. Used for SENS output and servo auto sequencer.
24	MON	O	Spindle motor ON/OFF control output.
25	MDP	O	Spindle motor servo control output.
26	MDS	O	Spindle motor servo control output. (Not used)
27	LOCK	O	GFS is sampled by 460Hz. H output when GFS is H. L output when GFS is L for 8 consecutive times.
28	TEST1	I	TEST. (Connected to GND)
29	FILO	O	Filter output to master PLL. (slave=digital PLL)
30	FILI	I	Filter input to master PLL.
31	PCO	O	Charge-pump output to master PLL.
32	VDD	—	Power supply input. (+5V)
33	AVSS1	—	GND.
34	CLTV	I	VCO control voltage input to master PLL.
35	AVDD1	—	Power supply input. (+5V)
36	RF	I	EFM signal input.
37	BIAS	I	Constant current input to asymmetry correction circuit.
38	ASYI	I	Comparate voltage input to asymmetry correction circuit.
39	ASYO	O	EFM full swing output. (L=VSS, H=VDD)
40	ASYE	I	L: asymmetry correction OFF. H: asymmetry correction ON (connected to +5V)
41	WDCK	O	D/A interface, word clock (2Fs) for 48-bit slot. (Not used)
42	LRCK	O	D/A interface, LR clock (Fs) for 48-bit slot.

Pin No.	Pin Name	I/O	Description
43	LRCKI	I	LR clock input to DAC. (48-bit slot)
44	PCMD	O	D/A interface, serial data. (2's complement, MSB first)
45	PCMDI	I	Audio data input to DAC. (48-bit slot)
46	BCK	O	D/A interface, bit clock.
47	BCKI	I	Bit clock input to DAC. (48-bit slot)
48	GTOP	O	GTOP output. (Not used)
49	XUGF	O	XUFG output. (Not used)
50	XPCK	O	XPLCK output. (Not used)
51	GFS	O	GFS output. (Not used)
52	RFCK	O	RFCK output. (Not used)
53	VSS	—	GND.
54	C2PO	O	C2PO output. (Not used)
55	XROF	O	XRAOF output. (Not used)
56	MNT3	O	MNT3 output. (Not used)
57	MNT1	O	MNT1 output. (Not used)
58	MNT0	O	MNT0 output. (Not used)
59	FSTT	O	Pins-73 and -74 divided-by 2/3 output. (Not used)
60	C4M	O	4.2336MHz output. (Not used)
61	DOUT	O	Digital Out connector output signal.
62	EMPH	O	H when the playback disc has emphasis. L when it does not.
63	EMPHI	I	DAC emphasis ON/OFF. H when ON. L when OFF
64	WFCK	O	WFCK (WRITE FRAME CLOCK) output.
65	ZEROL	O	No sound data detection output. H (L-ch) when no sound data is detected. (Not used)
66	ZEROR	O	No sound data detection output. H (R-ch) when no sound data is detected. (Not used)
67	DTSI	I	TEST for DAC. (Connected to GND)
68	VDD	—	Power supply input. (+5V)
69	LPWM	O	L-ch PWM output. (normal polarity)
70	NLPWM	O	L-ch PWM output. (reversed polarity)
71	AVDD2	—	Power supply input to L-ch PWM driver. (Connected to +5V)
72	AVDD3	—	Power supply input to X'tal. (Connected to +5V)
73	XTAI	I	X'tal input to 33.8688MHz oscillator circuit.
74	XTAO	O	33.8688MHz X'tal oscillator circuit output.
75	AVSS1	—	Power supply input to X'tal. (Connected GND)
76	AVSS2	—	Power supply input to PWM driver. (Connected to GND)
77	NRPWM	O	R-ch PWM output. (reversed phase)
78	RPWM	O	R-ch PWM output. (normal phase)
79	DTS2	I	TEST-2 for DAC. (Connected GND)
80	DTS3	I	TEST-3 for DAC. (Connected GND)

IC,CXA1782BQ

Pin No.	Pin Name	I/O	Description
1	FEO	O	Focus error amplifier output pin. This pin is connected to the FZC comparator input internally.
2	FEI	I	Focus error input pin.
3	FDFCT	I	Capacitor connection pin for time constant used when there is defect.
4	FGD	I	Corrects the focus servo high frequency gain.
5	FLB	I	This is a pin where the time constant is externally connected to raise the low frequency gain of the focus servo.
6	FEO	O	Focus drive output.
7	FEM	I	Focus amplifier inverted input pin.
8	SRCH	I	This is a pin where the time constant is externally connected to generate the focus search waveform.
9	TGU	I	This is a pin where the selection time constant is externally connected to set the tracking servo the high frequency gain.
10	TG2	I	This is a pin where the selection time constant is externally connected to set the tracking high frequency gain.
11	FSET	I	Pin for setting peak of the phase compensator of the focus tracking.
12	TAM	I	Tracking amplifier inverted input pin.
13	TAO	O	Tracking drive output.
14	SLP	I	Sled amplifier non-inverted input pin.
15	SLM	I	Sled amplifier inverted input pin.
16	SLO	O	Sled drive output.
17	ISET	I	The current which determines height of the focus search, track jump and sled kick is input.
18	VCC	—	+ 5 V power supply pin.
19	CLK	I	Serial data transfer clock input from CPU (CXD2518Q).
20	XLT	I	Latch input from CPU (CXD2518Q).
21	DATA	I	Serial data input from CPU (CXD2518Q).
22	XRST	I	Reset input pin. Reset at L.
23	COUT	O	Signal output to count the number of tracks.
24	SENS	O	FZC, DFCT, TZC, Gain or BAL is output depending on the command from CPU (CXD2518Q).
25	FOK	O	Output pin of the focus OK comparator.
26	CC2	O	Input pin where the DEFECT bottom hold output is capacitance coupled.
27	CC1	I	DEFECT bottom hold output pin.
28	CB	I	This is a pin where the DEFECT bottom hold capacitor is connected.
29	CP	I	This is a pin where the MIRR hold capacitor is connected and MIRR comparator non-inverted signal is input.
30	RFI	I	Input pin where the RF summing amplifier output is capacitance coupled.
31	RFO	O	RF summing amplifier output pin. (TP1)
32	RFM	I	RF summing amplifier inverted input pin. Gain of RF amplifier is determined by the resistor connected between RFO and this pin.
33	LD	O	APC amplifier output pin.

Pin No.	Pin Name	I/O	Description
34	PHD	I	APC amplifier input pin.
35~36	PHD1~2	I	RF I-V amplifier inverted input pin. These pins are connected to the A+C and B+D pins of the optical pickup.
37	BIAS	I	Bias adjustment pin of the non-inverted side of the focus error amplifier.
38~39	F~E	I	F and E IV amplifier non-inverted input pins. These pins are connected to the F and E of the optical pickup.
40	EI	—	Gain adjustment pin of the I-V amplifier E.
41	VEE	—	GND connection pin
42	TEO	O	Tracking error amplifier output pin. E-F signal is output.
43	LPFI	I	BAL adjustment comparator input pin. Not used.
44	TEI	I	Tracking error input pin.
45	ATSC	I	Window comparator input pin for detecting ATSC.
46	TZC	I	Tracking zero-cross comparator input pin.
47	TDFCT	I	Capacitor connection pin for the time constant used when there is defect.
48	VC	O	DC voltage output pin of VREF. (VDD/2)

IC BLOCK DIAGRAM

IC,BA3837



IC,TC4052



TRUTH TABLE

CONTROL INPUTS			ON SWITCH	
INHIBIT	B	A		
L	L	L	Y0	X0
L	L	H	Y1	X1
L	H	L	Y2	X2
L	H	H	Y3	X3
H	X	X	—	—

L:LOW LEVEL
H:HIGH LEVEL
H:IRRELEVANT

IC,LA1836



IC,TC4094BP



IC,XR – 1071CP



IC,GD4052



PIN NAMES

Y0a - Y3a	Independent Inputs/Outputs
Y0b - Y3b	Independent Inputs/Outputs
A1, A1	Address Inputs
$\overline{E}$	Enable Input (Active LOW)
Za, Zb	Common Input/Output

TRUTH TABLE

INPUTS			CHANNELS			
E	A1	A0	Y0-Z	Y1-Z	Y2-Z	Y3-Z
L	L	L	ON	OFF	OFF	OFF
L	L	H	OFF	ON	OFF	OFF
L	H	L	OFF	OFF	ON	OFF
L	H	H	OFF	OFF	OFF	ON
H	X	X	OFF	OFF	OFF	OFF

L:LOW Level, H:HIGH Level, X:Don't care

IC,HA12134A



IC, BA6397FP



IC, TA7291



TRUTH TABLE

INPUT		OUTPUT		MODE
IN1	IN2	OUT1	OUT2	
0	0	∞	∞	STOP
1	0	H	L	CW
0	1	L	H	CCW
1	1	L	L	BRAKE

∞ : HI IMPEØANCE
NOTE : INPUT "H" ACTIVE

IC, BU4052B



TRUTH TABLE

INHIBIT	A	B	ON SWITCH
L	L	L	X0 Y0
L	H	L	X1 Y1
L	L	H	X2 Y2
L	H	H	X3 Y3
H	X	X	NONE

X:ØON'T CARE.

IC,XR1090



IC,LC7218



FL (BJ238GK) GRID ASSIGNMENT/ANODE CONNECTION

GRID ASSIGNMENT



ANODE CONNECTION

	G12	G11	G10	G9	G8	G7	G6	G5	G4	G3	G2	G1
P1	B10	B10	B10	B10	S3	2d	2d	2d	2d	2d	n	**20**
P2	B1	B1	B1	B1	B1	2j,2p	2j,2p	2j,2p	2j,2p	2j,2p	o	**19**
P3	B11	B11	B11	B11	**AUTO**	2n	2n	2n	2n	2n	3e	**18**
P4	B2	B2	B2	B2	B2	2r	2r	2r	2r	2r	3c	**17**
P5	B12	B12	B12	B12	(b)	2c	2c	2c	2c	2c	3a,3d,3g	**16**
P6	B3	B3	B3	B3	B3	2e	2e	2e	2e	2e	3b	**15**
P7	B13	B13	B13	B13	(#)	2m	2m	2m	2m	2m	2e	**14**
P8	B4	B4	B4	B4	B4	2g	2g	2g	2g	2g	2c	**13**
P9	B5	B5	B5	B5	B5	2f	2f	2f	2f	2f	2a,2d,2g	**12**
P10	B15	B15	B15	B15	▷	2b	2b	2b	2b	2b	l	**11**
P11	B6	B6	B6	B6	B6	2K	2K	2K	2K	2K	j	**10**
P12	B16	B16	B16	B16	◁	2h	2h	2h	2h	**MHz**	h	**9**
P13	B7	B7	B7	B7	B7	2a	2a	2a	2a	2a	k	**8**
P14	B14	B14	B14	B14	)	**PM(DOWN)**	col 2	col1 (UP)	**MONO**	**KHz**	2b	**7**
P15	B17	B17	B17	B17	(	**AM(DOWN)**	Dp	col1(DOWN)	((◎))	**5**	1e	**6**
P16	B8	B8	B8	B8	B8	**SLEEP**	1d	1d	1d	1d	1a,1d,1g	**5**
P17	B18	B18	B18	B18	o	**REC**	1e	1e	1e	1e	1c	**4**
P18	B9	B9	B9	B9	B9	**PM (UP)**	1c	1c	1c	1c	1b	**3**
P19	B19 (T-BASS)	B19 (BBE)	(ROCK)	(POP)	(DD) NR	**AM (UP)**	1g	1g	1g	1g	m	**2**
P20	B20	B20	(DISCO)	(LIVE)	(RECORD)	—	1f	1f	1f	1f	(A1)	**1**
P21	B21	B21	—	—	(CLASSIC)	/	1b	1b	1b	1b	⌐	(EDIT)
P22	B22	B22	—	—	(HALL)	(◎)	1a	1a	1a	1a	(PRGM)	(RANDOM)
ST1	S1 T-BASS	S1	S1 **ROCK**	S1 **POP**	S1	—	—	—	—	—	—	S2
ST2	—	**BBE**	—	—	—	—	—	—	—	—	—	—
ST3	—	—	**DISCO**	**LIVE**	**HALL**	—	—	—	—	—	—	—
ST4	—	—	—	—	b #	—	—	—	—	—	—	—

ELECTRICAL ADJUSTMENT

A MAIN C.B



P DECK2 C.B



DECK1 P, DECK2 R/P/E HEAD



① TUNER SECTION

1. Clock Frequency Adjustment
   Settings : • Test point : TP2 (CLK IC770 pin30)
   • Adjustment location : TC701
   Method : Set to AM 1710kHz and adjust TC701 so that the test point becomes 2160kHz ± 0.01kHz.

2. AM VT Check
   Settings : • Test point : TP1 (VT)
   Method : Set to AM 1710kHz and check that the test point is 6.5 ± 1.0V.

3. AM Tracking Adjustment
   Settings : • Test point : TP5,TP6
   • Adjustment location : L981
   Method : Set to AM 1000kHz and adjust L981 that the test point becomes maximum.

4. AM IF Adjustment
   Settings : • Test point : TP5,TP6
   L742 ..... 450kHz

5. FM VT Adjustment

Settings : • Test point : TP1 (VT)
• Adjustment location : L807

Method : Set to FM 87.5MHz and adjust L807 so that the test point becomes 1.7V ± 0.05V.

6. FM Tracking Adjustment

Settings : • Test point : TP5,TP6
TC801,TC802 ····· 108MHz
L802,L804 ····· 87.5MHz

7. DC Balance/MONO Distortion Adjustment

Settings : • Test point : TP3,TP4 (DC balance)
TP5,TP6 (Distortion)
• Adjustment location : L741
• Input level : 54dB

Method : Set to FM 98.0MHz and adjust L741 so that the voltage between TP3 and TP4 becomes 0V ± 0.04V.
Next check that the distortion becomes less than 1.3%.

8. Auto stop Level Adjustment

FM

Settings : • Test point : TP7
• Adjustment location : SFR722
• Input level : 18dB

Method : Set to FM 98.0MHz and adjust voltage low (about 0.01V) by SFR722. After that voltage high (about 7.0V) out by 2dB down.

AM

Settings : • Test point : TP7
• Adjustment location : SFR771
• Input level : 55dB

Method : Set to AM 1000kHz and adjust voltage low (about 0.01V) by SFR771. After that voltage high (about 7.0V) out by 2dB down.

TAPE SECTION

9. Tape Speed Adjustment

Settings : • Test tape : TTA-100
• Test point : TP5,TP6
• Adjustment location : SFR Ⓡ

Method : Play back the test tape DECK II and adjust SFR Ⓡ so that the frequency counter reads 3000Hz ± 5Hz.

10. Head Azimuth Adjustment

Settings : • Test tape : TTA-310
• Test point : TP5,TP6
• Adjustment location : Head azimuth adjustment screw

Method : Play back the 10kHz signal of the test tape and adjust screw so that the output becomes maximum. Next, perform on each FWD PLAY and REV PLAY mode.

11. PB Frequency Response Check

Settings : • Test tape : TTA-310
• Test point : TP5,TP6

Method : Play back the 315Hz and 10kHz signals of the test tape and check that the output ratio of the 10kHz signal is with respect to that of the 315Hz signal is ± 2dB.

12. PB Sensitivity Adjustment

Settings : • Test tape : TTA-200
• Test point : TP5,TP6
• Adjustment location :
(I DECK) SFR301 (Lch)
SFR302 (Rch)
(II DECK) SFR351 (Lch)
SFR352 (Rch)

Method : Play back the test tape and adjust SFRs so that the output level of the test point is 300mV.

13. REC/PB Frequency Response Adjustment

Settings : • Test tape : TTA-601
• Test point : TP5,TP6
• Input signal : 1kHz/10kHz (LINE IN)
• Adjustment location : SFR451 (Lch)
SFR452 (Rch)

Method : Apply a 1kHz signal and REC mode. Then adjust OSC attenuator so that the output level at the TP5,TP6 is 21mV. Record and play back the 1kHz and 10kHz signals and adjust SFRs so that the output of the 10kHz signal is 0dB ~ + 0.5dB with respect to that of the 1kHz signal.

14. REC/PB Sensitivity Adjustment

Settings : • Test tape : TTA-601
(TTA - 600)
• Test point : TP5,TP6
• Input signal : 1kHz (LINE IN)
• Adjustment location : SFR401 (Lch)
SFR402 (Rch)

Method : Apply a 1kHz signal and REC mode. Then adjust OSC attenuator so that the output level at the TP5,TP6 is 21mV. Record and play back the 1kHz signal and adjust SFRs so that the output is 21mV ± 0.5dB.

PRACTICAL SERVICE FIGURE

TUNER SECTION

< FM SECTION >

IHF Sensitivity :	4dB ± 6dB (87.5MHz)
(THD 3%)	2dB ± 6dB (98.0MHz)
	2dB ± 6dB (108.0MHz)
S/N 50dB Quieting sensitivity :	32dB ± 5dB (87.5/98.0/108.0MHz)
Signal to noise ratio :	More than 64dB (98.0MHz)
Distortion :	Less than 1.2% (98.0MHz)
Stereo separation :	More than 25dB (98.0MHz)
Intermediate frequency :	10.7MHz

< AM SECTION >

Sensitivity :	55dB ± 7dB (603kHz)
(S/N 20dB)	53dB ± 6dB (999kHz)
	53dB ± 6dB (1404kHz)
Distortion :	Less than 1.5% (999kHz)
Stereo separation :	More than 12dB (999kHz)
Intermediate frequency :	450kHz

TAPE SECTION

Tape speed :	3000Hz ± 1.5%
Wow & flutter :	Less than 0.4% (R.M.S)
Take-up torque :	30~55g-cm (FWD, REV)
F.F torque :	75~180g-cm
Rew torque :	75~180g-cm
Back tension :	2~7g-cm
PB Output level :	2.8V ± 1.5dB (SP OUT)
REC/PB Output level :	2.0V ± 2.0dB (SP OUT)
Distortion (REC/PB) :	Less than 2% (NORM)
Noise level (PB) :	Less than 200mV (DOLBY B NR OFF NORM, Vol MAX.)
Noise level (REC/PB) :	Less than 35mV (DOLBY B NR OFF NORM, SP OUT, 2V)
Crosstalk :	More than 60dB (1kHz, 0VU)
Erasing ratio :	More than 60dB (125Hz)
Channel separation :	More than 40dB (1kHz, 0VU)
REC bias frequency :	85kHz
Test tape :	NORMAL TTA-601/600

ADJUSTMENT

[C] 3CD C.B



Note : Connect a probe (10 : 1) of the osilloscope or the frequency counter to a test point.

1. Focus Bias Adjustment
   Make the focus bias adjustment when replacing and repairing the optical block.



1) Connect an oscilloscope to the test points TP1 (RF) and TP2 (VREF).
2) Turn on the power switch.
3) Insert test disc TCD-782 (YEDS-18) and play back the second composition.
4) Adjust SFR2 so that RF signal of the test point TP1 (RF) is MAX and CLEARREST.



Note : The current of the laser signal can be checked with the voltages on both sides of R23 (10 Ω). The difference for the specified value shown on the lavel must be withim ± 6.0mA.



$$\text{Laser current Iop} = \frac{\text{Voltage across R23}}{10\,\Omega}$$

2. TRACKING Balance Adjustment



1) Connect an oscilloscope to the test points TP3 (TE) and TP2 (VREF).
2) Turn on the power switch.
3) Insert test disc TCD-782 (YEDS-18) and press the PLAY button.
4) Connect the intermediate point of SFR1 to TP2 (VREF).
5) Adjust SFR3 so that the waveform on the oscilloscope is vertically symmetrical as shown in the figure below.
6) After the adjustment is completed, remove the connected lead wires from the terminals.



A = B VOLT/DIV : 200mV
TIME/DIV : 1mS

3. TRACKING Gain Adjustment

A servo analyzer is necessary in order to perform this adjustment exactly. However, this gain has margin, so even if it is slightly off, there is no problem. Therfore, do not perform this adjustment.

Focus/tracking gain determines the pick-up follow-up (vertical and horizontal) relative to mechanical noise and mechinical shock when 2-axis device operates. However, as these reciprocate, the adjustment is at the point where both are satisfied.

- When gain is raised, the noise increases when the 2-axis device opearates.
- When gain is lowered, it is more susceptible to mechanical shock and skipping occurs more easily.

When gain adjustment is off, the symptoms below appear.

Symptoms \ Gain	(Focus)	Tracking
● The time until music starts becomes longer for STOP→▶PLAY or automatic selection (⏮ ⏭buttons pressed.) (Normally takes about 2 seconds.)	low	low or high
● Music does not start and disc continues to rotate for STOP→▶PLAY or automatic selection (⏮ ⏭buttons pressed.)	–	low
● Disc stops to rotate shortly after STOP→▶PLAY.	low or high	–
● Sound is interrupted during PLAY. Or time counter display stops.	–	low
● More noises during the 2-axis device operation.	high	high

The following is simple adjustment method.

– Simple adjustment –

Note : Since exact adjustment cannot be performed, remember the positions of the controls before the performing the adjustment. If the positions after the simple adjustment are only a little different, return the controls to the original position.

Procedure



1) Keep the set horizontal.(If the set is not kept horizontally, this adjustment cannot be performed due to the gravity against the 2 – axis device.)
2) Insert test disc TCD-782 (YEDS-18) and play back the second composition.
3) Connect an oscilloscope to TP3 (TE) of the 3CD C.B

4) Adjust SFR1 so that the waveform appears as shown in the figure below.(tracking gain adjustment)



VOLT/DIV : 5mV
TIME/DIV : 1mS

● Incorrect example

Low tracking gain

(The fundamental wave appears as compared with the waveform adjusted)



VOLT/DIV : 5mV
TIME/DIV : 1mS

High tracking gain

(The frequency of the fundamental wave is higher than in low gain.)



VOLT/DIV : 5mV
TIME/DIV : 1mS

SPRING APPLICATION POSITION





MECHANICAL EXPLODED VIEW 1/2



MECHANICAL PARTS LIST 1/2

DESCRIPTIONで判断できない物は "REFERENCE NAME LIST" を参照してください。
If can't understand for Description please kindly refer to "REFERENCE NAME LIST".

REF. NO	PART NO.	ｶﾝﾘ NO.	DESCRIPTION
1	83-NFF-011-010		CAB, FR U〈5100U〉
1	83-NFF-038-010		CAB, FR U 5200〈5200U〉
1	83-NFF-054-010		CAB, FR U 5250〈5250U〉
2	83-NF5-007-110		WINDOW, CASS 2
3	83-NF5-012-110		KEY, PLAY
4	83-NF5-004-010		BOX, CASS 2
5	82-NF5-219-010		SPR-T, EJECT 2 (SIN)
6	82-NF5-218-010		SPR-T, EJECT 1 (SIN)
7	83-NF5-003-010		BOX, CASS 1
8	80-CD3-218-110		SPR-P CASS
9	83-NF5-006-110		WINDOW, CASS 1
10	83-NF5-020-010		KNOB, MIC
11	81-532-080-010		LBL, CASS-COMPT
12	83-NFF-020-010		WINDOW, DISPLAY
13	87-063-165-010		OIL-DMPR 150
14	83-NF5-022-010		WINDOW, CD
15	82-NE6-067-010		BADGE, AIWA 30N
16	83-NF5-013-010		KEY, POWER
17	83-NF5-202-010		GUIDE, FL
18	83-NF5-206-010		GUIDE, LED
19	82-NF5-217-210		HLDR, BOTTOM
20	83-NFF-024-010		PANEL, TRAY E
21	83-NF5-034-010		IND, CD 2
22	83-NF5-023-010		IND, CD
23	83-NF5-021-010		WINDOW, TOP
24	83-NF5-033-010		CAB, STEEL HR
25	83-NF5-014-110		KEY ASSY, FUN
26	83-NFF-042-010		PANEL, REAR UB5200〈5200U〉
26	83-NFF-012-010		PANEL, REAR UBNM〈5100U〉
26	83-NFF-041-010		PANEL, REAR UBNM 5250〈5250U〉
27	87-050-053-010		AC CORD ASSY, U-Z
28	87-085-189-010		BUSHING, CORD U
29	87-085-221-010		FOOT, H13.5
30	83-NF5-025-010		KEY, REC
31	82-NF5-227-010		HLDR, LOCK 2N
32	83-NF5-029-110		KEY, DISC
33	82-NF5-228-010		SPR-C, LOCK
34	82-NF5-229-010		PLATE, LOCK
35	82-NF5-226-010		HLDR, LOCK 1N
36	83-NF5-009-010		KNOB, VOL
37	83-NF5-010-010		IND, VOL
38	83-NF5-030-010		PANEL, GEQ〈5100U〉
38	83-NFF-005-010		PANEL, GEQ D〈5250U, 5200U〉
39	83-NF5-026-010		KEY, GEQ〈5100U〉
39	83-NFF-006-010		KEY, GEQ D〈5250U, 5200U〉
40	83-NFF-007-110		KEY, ECHO
41	83-NF5-207-010		HLDR, FFC
42	83-NF5-024-010		KEY, OPEN
43	84-711-909-010		LBL, DATE
A	87-067-641-010		UTT2+3-8(W/O SLOT)BL
B	87-067-703-010		BVT2+3-10 (W/O SLOT)
C	87-571-032-410		VIT+2-3
D	87-067-633-010		BVT2+3-8 W CONVEX
E	87-067-698-010		BVT2+3-18(W/O, SLOT)
F	87-067-758-010		BVT2+3-12 W/O SLOT
G	87-067-688-010		BVTT+3-6
H	87-591-094-410		QIT+3-6
I	87-078-083-010		BVTT SEMS+4-8SW
J	87-721-097-410		QT2+3-12 GLD
K	87-067-579-010		BVT2+3-8W/O SLOT
L	87-741-094-410		UT2+3-6

MECHANICAL EXPLODED VIEW 2/2



MECHANICAL PARTS LIST 2/2

DESCRIPTIONで判断できない物は "REFERENCE NAME LIST" を参照してください。
If can't understand for Description please kindly refer to "REFERENCE NAME LIST".

REF. NO	PART NO.	ｶﾝﾘ NO.	DESCRIPTION
1	80-CD3-214-010		CUSH CD A
2	81-ZG1-277-010		HLDR, MAGNET N
3	81-ZG1-253-510		HLDR, MECH MK2
4	81-ZG1-276-110		WORM GEAR, TT NO2
5	81-ZG1-230-010		G-CUSH, MECH
6	81-ZG1-231-110		SPR-C, MECH
7	81-ZG1-212-010		PULLY, LOAD MO
8	81-ZG1-250-010		GEAR, TRAY RELAY MK2
9	81-ZG1-019-010		GEAR, TRAY B YEL
10	81-ZG1-018-010		GEAR, TRAY A YEL
11	81-ZG1-017-010		GEAR, RELAY RED
12	81-ZG1-014-010		PULLY, RELAY YEL
13	81-ZG1-240-010		SPR-P, WORM
14	87-036-326-010		MAGNET, CLAMPER 93
15	81-ZG1-285-010		PLATE, MAGNET N
16	81-ZG1-232-010		BELT, TRAY
17	81-ZG1-238-110		CUSH, TRAY IN
18	81-ZG1-222-010		WORM WHEEL, TT
19	81-ZG1-202-010		GEAR MAIN
20	81-ZG1-252-010		LEVER, TT MK2
21	81-ZG1-008-210		TURNTABLE, NO2〈5100U, 5250U〉
21	81-ZG1-010-210		TURNTABLE, NO3〈5200U〉
22	81-ZG1-020-010		PLATE, CAM BGE
23	81-ZG1-262-010		SPR-E, CAM S
24	81-ZG1-016-010		GEAR, MECH CAM BGE
25	81-ZG1-024-010		TRAY, NO3 3NF-5
26	81-ZG1-015-010		GEAR, TRAY CAM BLU
27	81-ZG1-233-110		BELT, TT
28	81-ZG1-236-010		PULLY, TT MO
29	81-ZG1-260-010		SHAFT, WORM S
A	81-653-215-010		SPECIAL SCREW VT2
B	81-ZG1-254-010		S-SCREW, MECH HLDR
C	81-ZG1-271-010		S-SCREW, MECH REAR
D	81-ZG1-239-010		S-SCREW, TT
E	87-067-945-110		VFT2+3-12(F10)
F	87-251-071-410		U+2.6-4
G	87-067-579-010		BVT2+3-8W/O SLOT
H	81-ZG1-264-010		S-SCREW, CAM
I	87-761-095-410		VFT2+3-8
J	87-078-029-010		VFT2+3-13(F8)
K	87-078-061-010		VFT2+3-20DIA10, GLD

CD MECHANISM EXPLODED VIEW 1/1



CD MECHANISM PARTS LIST 1/1

DESCRIPTIONで判断できない物は "REFERENCE NAME LIST" を参照してください。
If can't understand for Description please kindly refer to "REFERENCE NAME LIST".

REF. NO	PART NO.	ｶﾝﾘ NO.	DESCRIPTION
1	9X-262-513-310		T.T CHASS ASSY W/MOTOR
2	92-625-188-020		GEAR(A)
3	92-625-544-010		COVER
4	92-625-187-010		RING CENTER
5	92-625-191-010		SPRING COMPRESSION
6	98-848-127-110		OPTICAL PICK UP KSS-210A
7	94-917-565-010		SHAFT SLED
A	87-261-032-210		V+2-3

TAPE MECHANISM EXPLODED VIEW 1/1





TAPE MECHANISM PARTS LIST 1/1

DESCRIPTIONで判断できない物は "REFERENCE NAME LIST" を参照してください。
If can't understand for Description please kindly refer to "REFERENCE NAME LIST".

REF. NO	PART NO.	ｶﾝﾘ NO.	DESCRIPTION
1	82-ZM3-214-110		CHAS ASSY, P (DECK 1)
1	82-ZM1-299-010		CHAS ASSY, R (DECK 2)
2	82-ZM1-258-010		SPR-T, PINCH L
3	82-ZM1-248-110		LVR ASSY, PINCH L
4	82-ZM1-295-210		PLATE ASSY, LINK
5	82-ZM1-266-010		LVR, DIR
6	82-ZM1-214-010		SPR-T, DIR
7	82-ZM1-206-210		CHAS, HEAD
8	87-078-014-010		SH, 5-5-0.05
9	82-ZM1-269-010		SPR-T, BRG
10	82-ZM1-219-010		SPR-T, LINK
11	82-ZM1-210-010		GEAR, H T
12	82-ZM1-213-010		SPR-T, HEAD
13	82-ZM1-207-010		GUIDE, TAPE
14	82-ZM1-283-210		S-SCREW, AZIMUTH
15	82-ZM1-209-010		PLATE, HEAD
16	82-ZM1-208-010		HLDR, HEAD
17	82-ZM1-218-010		SPR-E, HB
18	82-ZM1-263-110		LVR, EJECT L (DECK 1)
18	82-ZM1-264-010		LVR, EJECT R (DECK 2)
19	82-ZM1-222-010		LVR, PLAY
20	82-ZM1-217-110		REEL TABLE
21	82-ZM1-244-110		SPR-C, BT
22	82-ZM1-285-110		SPR-C, BT L
23	82-ZM1-257-010		SPR-T, CAS
24	82-ZM1-241-110		LVR, MC
25	82-ZM1-242-010		LVR, CAS
26	82-ZM1-243-010		LVR, STOP
27	82-ZM1-253-110		LVR ASSY, PINCH R
28	82-ZM1-259-010		SPR-T, PINCH R
29	82-ZM1-240-110		LVR, REC (DECK 2)
30	82-ZM1-298-010		SPR-P, EARTH
31	82-ZM1-255-110		SPR-E, LVR DIR
32	82-ZM1-221-110		GEAR, CAM
33	82-ZM1-227-110		LVR, TRIG
34	82-ZM1-224-110		LVR, FR
35	82-ZM1-305-010		SPR-E, TRIG 2
36	82-ZM1-277-010		SPR-C, PLAY
37	82-ZM1-223-010		GEAR, PLAY
38	82-ZM1-256-110		SPR-T, FR
39	82-ZM1-220-210		GEAR, IDLER
40	80-ZM6-217-010		RING MAGNET 2
41	82-ZM1-216-210		GEAR, REEL
42	82-ZM1-276-010		SPR-C, FR
43	82-ZM1-225-010		GEAR, FR
44	82-ZM1-226-010		GEAR, REW
45	82-ZM1-228-210		SLIP DISK ASSY
46	82-ZM1-261-110		BELT, FR
47	82-ZM1-237-210		FLY-WHL ASSY, R (DECK 2)
47	82-ZM3-209-110		FLY-WHL ASSY, R2 (DECK 1)
48	82-ZM1-234-110		FLY-WHL ASSY, L (DECK 2)
48	82-ZM3-207-210		FLY-WHL ASSY, L2 (DECK 1)
49	82-ZM3-206-010		BELT, R
50	82-ZM1-245-210		HLDR, IC
51	82-ZM3-201-010		HLDR, MC
52	82-ZM3-202-010		PULLEY, MOT 2M
53	82-ZM1-288-010		SH, 1.63-3.2-0.5 SLT
54	80-ZM6-243-010		SH, 1.75-3.6-0.5 SLT
55	80-ZM6-230-010		SH, BELT
56	86-575-242-010		CUSH-G, DIA3.7-9-3.2
57	86-575-361-010		CUSH-G, 6-8-0.8
58	82-ZM3-205-010		BELT, L
59	82-ZM3-204-010		PULLEY, COUPLER (DECK 1)
60	87-045-347-010		MOT, SHU2L 70(M1)
61	87-046-355-010		HEAD, PH HADKH2529B(PH)
61	87-046-356-010		HEAD, RPH HADKH5581B(RPH)
A	87-585-036-410		UIT+2-8
B	80-ZM6-207-010		V+1.6-7
C	82-ZM1-309-010		S-SCRW, MOTOR
D	87-067-178-010		VTT+2.6-3
E	87-067-932-010		PW, 2.15-6.8-0.5 SLT
F	87-067-972-010		PW, 1.05-3-0.25 SLT

■ SPEAKER LIST

DESCRIPTIONで判断できない物は "REFERENCE NAME LIST" を参照してください。
If can't understand for Description please kindly refer to "REFERENCE NAME LIST".

REF. NO	PART NO.	カンリ NO.	DESCRIPTION
SX-N5200			
1	83-NSF-009-010		PANEL FR L B
2	83-NSF-008-010		PANEL FR R B
3	83-NSF-011-010		GRILL FRAME ASSY L
4	83-NSF-010-010		GRILL FRAME ASSY R
5	83-NSF-610-010		SPEAKER WOOFER U
6	82-NS5-604-010		SPEAKER TWEETER
7	82-MSE-610-010		CERAMIC
8	83-096-614-010		SPEAKER CORD
9	83-NSF-013-010		DIAPHRAGM

■ ACCESSORIES／PACKAGE LIST

DESCRIPTIONで判断できない物は "REFERENCE NAME LIST" を参照してください。
If can't understand for Description please kindly refer to "REFERENCE NAME LIST".

REF. NO	PART NO.	カンリ NO.	DESCRIPTION
1	83-NFF-906-010		IB, U(S)
2	83-NFF-605-010		RC, RC-TN520EX〈5100〉
2	83-NFF-621-010		RC, RC-TN5200EXU〈5200, 5250〉
3	87-006-225-010		AM LOOP ANT NC2
4	87-043-115-010		ANT, FEEDER FM

REFERENCE NAME LIST

ELECTRICAL SECTION

DESCRIPTION	REFERENCE NAME
ANT	ANTENNAS
C-	CHIP
C-CAP	CAP, CHIP
C-CAP TN	CAP, CHIP TANTALUM
C-COIL	COIL, CHIP
C-DI	DIODE, CHIP
C-DIODE	DIODE, CHIP
C-FET	FET, CHIP
C-FOTR	FILTER, CHIP
C-JACK	JACK, CHIP
C-LED	LED, CHIP
C-RES	RES, CHIP
C-SFR	SFR, CHIP
C-SLIDE SW	SLIDE SWITCH, CHIP
C-SW	SWITCH, CHIP
C-TR	TRANSISTOR, CHIP
C-VR	VOLUME, CHIP
C-ZENER	ZENER, CHIP
CAP, CER	CAP, CERA-SOL
CAP, E	CAP, ELECT
CAP, M/F	CAP, FILM
CAP, TC	CAP, CERA-SOL
CAP, TC-U	CAP, CERA-SOL SS
CAP, TN	CAP, TANTALUM
CERA FIL	FILTER, CERAMIC
CF	FILTER, CERAMIC
DL	DELAY LINE
E/CAP	CAP, ELECT
FILT	FILTER
FLTR	FILTER
FUSE RES	RES, FUSE
MOT	MOTOR
P-DIODE	PHOTO DIODE
P-SNSR	PHOTO SENSER
P-TR	PHOTO TRANSISTOR
POLY VARI	VARIABLE CAPACITOR
PPCAP	CAP, PP
PT	POWER TRANSFORMER
PTR, RES	PTR, MELF
RC	REMOTE CONTROLLER
RES NF	RES, NON-FLAMMABLE
RESO	RESONATOR
SHLD	SHIELD
SOL	SOLENOID
SPKR	SPEAKER
SW, LVR	SWITCH, LEVER
SW, RTRY	SWITCH, ROTARY
SW, SL	SWITCH, SLIDE
TC CAP	CAP, CERA-SOL
THMS	THERMISTOR
TR	TRANSISTOR
TRIMMER	CAP, TRIMMER
TUN-CAP	VARIABLE CAPACITOR
VIB, CER	RESONATOR, CERAMIC
VIB, XTAL	RESONATOR, CRYSTAL
VR	VOLUME
ZENER	DIODE, ZENER
ｻｰｼﾞｻﾌﾟﾚｯｻ	SERGESUPPRESSOR
ｾﾗｺﾝ	CAP, CERA

サービス技術ニュース	
番号	連絡内容
G－　－	
G－　－	
G－　－	

MECHANICAL SECTION

DESCRIPTION	REFERENCE NAME
ADHESHIVE	SHEET ADHESHIVE
AZ	AZIMUTH
BAR-ANT	BAR-ANTENNA
BAT	BATTERY
BATT	BATTERY
BRG	BEARING
BTN	BUTTON
CAB	CABINET
CASS	CASSETTE
CHAS	CHASSIS
CLR	COLLAR
CONT	CONTROL
CRSR	CURSOR
CU	CUSHION
CUSH	CUSHION
DIR	DIRECTION
DUBB	DUBBING
FL	FRONT LOADING
FLY-WHL	FLYWHEEL
FR	FRONT
FUN	FUNCTION
G-CU	G-CUSHION
HDL	HANDOL
HIMERON	CLOTH
HINGE, BAT	HINGE, BATTERY
HLDR	HOLDER
HT-SINK	HEAT SINK
IB	INSTRUCTION BOOKLET
IDLE	IDLER
IND, L-R	INDICATOR, L-R
KEY, CONT	KEY, CONTROL
KEY, PRGM	KEY, PROGRAM
KNOB, SL	KNOB, SLIDE
LBL	LABEL
LID, BATT	LID, BATTERY
LID, CASS	LID, CASSETTE
LVR	LEVER
P-SP	P-SPRING
PANEL, CONT	PANEL, CONTORL
PANEL, FR	PANEL, FRONT
PRGM	PROGRAM
PULLY, LOAD MO	PULLY, LOADING MOTOR
RBN	RIBBON
S-	SPECIAL
SEG	SEGMENT
SH	SHEET
SHLD-SH	SHIELD-SHEET
SL	SLIDE
SP	SPRING
SP-SCREW	SPECIAL-SCREW
SPACER, BAT	SPACER, BATTERY
SPR	SPRING
SPR-P	P-SPRING
SPR-PC-PUSH	P-SPRING, C-PUSH
T-SP	T-SPRING
TERM	TERMINAL
TRIG	TRIGGER
TUN	TUNING
VOL	VOLUME
W	WASHER
WHL	WHEEL
WORM-WHL	WORM-WHEEL
ｼｸｱｰﾑ	ARM, SHAFT
ｼｸｶﾞｲﾄﾞ	GUIDE, SHAFT
ｽﾄﾗｯﾌﾟ	STRAP
ﾄｸﾅﾍﾞ	S-SCRW
ﾋﾝｼﾞ	HINGE
ﾋﾝｼﾞﾋﾞｽ	S-SCRW
ﾋﾞｽｾﾚｰﾄ	SCRW, SERRART

アイワ株式会社
AIWA CO.,LTD.

931196, 750038
Tokyo Japan

〒110 東京都台東区池之端1－2－11　☎03 (3827) 3111 (代表)

Printed in Singapore

aiwa

aiwa SERVICE

NSX-550G
NSX-520
CX-N5250
CX-N5200
CX-N5150
CX-N550G
CX-N540
CX-N520

SERVICE MANUAL



COMPACT DISC STEREO SYSTEM

- BASIC TAPE MECHANISM: 2ZM-3 PR1
- BASIC CD MECHANISM: 4ZG-1GDFR <550G>
  4ZG-1DFR <EXCEPT 550G>
- TYPE: HE,HR,HM,LH,HD,HS
  U,C,EEZ,EZ,EE,K,G

SUPPLEMENT

- CD mechanism of NSX-550G/520,CX-N5250/N5200/N5150/N550G/N540/N520 is changed from 1ZG-1 to 4ZG-1

- This Service Manual contains only electrical adjustment for CD block of NSX-550G/520,CX-N5250/N5200/N5150/N550G/N540/N520.
  For CD biock, see Service Manual of 4ZG-1 (S/M Code No. 09-046-056-10T).
  If requiring the other information, see Service Manual
  NSX-550G ‹HE› (S/M Code No. 09-944-053-20T),
  NSX-550G ‹HR› (S/M Code No. 09-946-060-70T),
  NSX-550G ‹HD,HS› (S/M Code No. 09-949-071-50T),
  NSX-520 ‹HE,HR,HM,LH› (S/M Code No. 09-945-053-60T),
  NSX-520 ‹HD› (S/M Code No. 09-947-061-40T),
  CX-N5250/N5200/N5150 ‹U› (S/M Code No. 09-945-054-50T),
  CX-N5200 ‹C› (S/M Code No. 09-94B-086-30T),
  CX-N550G/N540 ‹EEZ,EZ,EE.K› (S/M Code No. 09-947-060-90T),
  CX-N520 ‹EZ,EE,K› (S/M Code No. 09-946-055-80T),
  CX-N520 ‹G› (S/M Code No. 09-94A-074-10T).

S/M Code No. 09-94B-086-60T

A 3CD C.B


IC803
IC801
SFR13 (TG)
SFR12 (TB)
SFR11 (FB)
R36
TP3 (TE)
41
31
IC201
TP2 (VREF)
TP1 (RF)
IC101
IC501
2
3
2
3
1
2
3
1
2
1

Note : Connect a probe (10 : 1) of the osilloscope or the frequency counter to a test point.

1. Focus Bias Adjustment

Make the focus bias adjustment when replacing and repairing the optical block.



1) Connect an oscilloscope to test points TP1 (RF) and TP2 (VREF).
2) Turn on the power switch.
3) Insert test disc TCD-782 (YEDS-18) and play back the second composition.
4) Adjust SFR11 so that RF signal of test point TP1 (RF) is MAX and CLEARREST.



Note : The current of the laser signal can be checked with the voltages on both sides of R28 (10 Ω). Thedifference for the specified value shown on the lavel must be withim ± 6.0mA.



$$\text{Laser current Iop} = \frac{\text{Voltage across R28}}{10\,\Omega}$$

2. Tracking Balance Adjustment



1) Connect an oscilloscope to test points TP3 (TE) and TP2 (VREF).
2) Turn on the power switch.
3) Insert test disc TCD-782 (YEDS-18) andpress the PLAY button.
4) Connect the intermediate point of SFR13 to TP2 (VREF).
5) Adjust SFR12 so that the waveform on the oscilloscope is vertically symmetrical as shown in the figure below.
6) After the adjustment is completed, remove the connected lead wires from the terminals.



3. Tracking Gain Adjustment

A servo analyzer is necessary in order to perform this adjustment exactly. However, this gain has margin, so even if it is slightly off, there is no problem. Therfore, do not perform this adjustment.

Focus/tracking gain determines the pick-up follow-up (vertical and horizontal) relative to mechanical noise and mechinical shock when 2-axis device operates. However, as these reciprocate, the adjustment is at the point where both are satisfied.

- When gain is raised, the noise increases when the 2-axis device opearates.
- When gain is lowered, it is more susceptible to mechanical shock and skipping occurs more easily.

When gain adjustment is off, the symptoms below appear.

Gain / Symptoms	(Focus)	Tracking
● The time until music starts becomes longer for STOP→▶PLAY or automatic selection (⏮ ⏭ buttons pressed.) (Normally takes about 2 seconds.)	low	low or high
● Music does not start and disc continues to rotate for STOP→▶PLAY or automatic selection (⏮ ⏭ buttons pressed.)	–	low
● Disc stops to rotate shortly after STOP→▶PLAY.	low or high	–
● Sound is interrupted during PLAY. Or time counter display stops.	–	low
● More noises during the 2-axis device operation.	high	high

The following is simple adjustment method.

– Simple adjustment –

Note : Since exact adjustment cannot be performed, remember the positions of the controls before the performing the adjustment. If the positions after the simple adjustment are only a little different, return the controls to the original position.

Procedure



サービス技術ニュース	
番 号	連絡内容
G – –	
G – –	
G – –	

1) Keep the set horizontal.(If the set is not kept horizontally, this adjustment cannot be performed due to the gravity against the 2 – axis device.)
2) Insert test disc TCD-782 (YEDS-18) and play back the second composition.
3) Connect an oscilloscope to TP3 (TE),TP2 (VREF) of the CD C.B.
4) Adjust SFR3 so that the waveform appears as shown in the figure below.(tracking gain adjustment)



VOLT/DIV : 50mV
TIME/DIV : 1mS

● Incorrect example

Low tracking gain

The fundamental wave appearsas compared with the waveform adjusted.



VOLT/DIV : 50mV
TIME/DIV : 1mS

High tracking gain

The frequency of the fundamental wave is higher than in low gain.



VOLT/DIV : 50mV
TIME/DIV : 1mS

アイワ株式会社
AIWA CO.,LTD.

931196 750038

Tokyo Japan

〒110 東京都台東区池之端 1 – 2 –11 ☎ 03 (3827) 3111 (代表)

Printed in Japan

aiwa

aiwa SERVICE

4ZG-1



CD MECHANISM

• BASIC CD MECHANISM:3ZG-2 E1

• TYPE: English

BASIC NAME	DERIVATION NAME					
4ZG-1	V	O	S1	D	SH	

■ This Service Manual has various derivation.Derivation name is indicated by the Service Manual for each model.

SERVICE MANUAL

S/M Code No 09-985-249-80T

PROTECTION OF EYES FROM LASER BEAM DURING SERVICING

This set employs laser. Therefore, be sure to follow carefully the instructions below when servicing.

WARNING!

WHEN SERVICING, DO NOT APPROACH THE LASER EXIT WITH THE EYE TOO CLOSELY. IN CASE IT IS NECESSARY TO CONFIRM LASER BEAM EMISSION. BE SURE TO OBSERVE FROM A DISTANCE OF MORE THAN 30cm FROM THE SURFACE OF THE OBJECTIVE LENS ON THE OPTICAL PICK-UP BLOCK.



- Caution: Invisible laser radiation when open and interlocks defeated avoid exposure to beam.
- Advarsel: Usynling laserstråling ved åbning, når sikkerhedsafbrydere er ude af funktion. Undgå udsættelse for stråling.

VAROITUS!

Laiteen Käyttäminen muulla kuin tässä käyttöohjeessa mainitulla tavalla saattaa altistaa käyt-täjän turvallisuusluokan 1 ylittävälle näkymättömälle lasersäteilylle.

VARNING!

Om apparaten används på annat sätt än vad som specificeras i denna bruksanvising, kan användaren utsättas för osynling laserstrålning, som överskrider gränsen för laserklass 1.

CAUTION

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

ATTENTION

L'utilisation de commandes, réglages ou procédures autres que ceux spécifiés peut entraîner une dangereuse exposition aux radiations.

ADVARSEL!

Usynlig laserstråling ved åbning, når sikkerhedsafbrydereer ude af funktion. Undgå udsættelse for stråling.

This Compact Disc player is classified as a CLASS 1 LASER product.
The CLASS 1 LASER PRODUCT label is located on the rear exterior.



Precaution to replace Optical block (KSS-213F)

Body or clothes electrostatic potential could ruin laser diode in the optical block. Be sure ground body and workbench, and use care the clothes do not touch the diode.

1) After the connection, remove solder shown in the right figure.

PICK-UP Assy P.C.B



This is the SERVICE MANUAL for the BASIC CD MECHANISM of BASIC NAME: 4ZG-1. This BASIC NAME includes the following models as shown under the SUFFIX name: DERIVATION NAME. Please use this manual with the separate SERVICE MANUAL for DERIVATION NAME.



BASIC NAME	DERIVATION NAME							
4ZG-1	V	O	S1	D	SH	—	—	—

DERIVATION NAME

- V: VIDEO OUT
- O: On screen display
- S1: THE 1st SONY IC MODEL
- D: Digital output function
- SH: Pick up equipped with shutter

How to Adjust the Rotating Phase of the Gear, Main Cam

1) Push down the hooking catch of the CHAS. MECH, and remove the TRAY.
2) Align the arrow mark of the Gear, Main Cam with the black round mark of the CHAS, MECHA as shown below.
3) Confirm that the Slide, Mech Cam is located in the right position, then insert the TRAY gently.

Caution: If the rotating phase of the Gear, Main Cam is incorrectly adjusted, the chucking operation and tray movement will have malfunction.



ELECTRICAL MAIN PARTS LIST

DESCRIPTIONで判断できない物は "REFERENCE NAME LIST" を参照してください。
If can't understand for Description please kindly refer to "REFERENCE NAME LIST".

REF. NO	PART NO.	KANRI NO.	DESCRIPTION
IC			
	87-A20-547-010		C-IC,CXA1992AR
	87-A20-919-040		C-IC,BA5915FP
	87-A20-917-010		C-IC,CXD2540Q-1/2
	84-ZG1-697-010		C-IC,UPD78016FGC-549
	87-017-825-010		IC,GP1F32T
	87-017-760-080		IC,M51943BML
	87-A20-602-040		C-IC,M5291FP
	87-A20-925-040		C-IC,BA05FP
	87-A20-905-040		C-IC,BA033FP
	87-001-873-010		IC,LB1644
	87-A20-920-010		C-IC,CL680-D1
	87-A20-921-040		C-IC,SN74LVU04APW
	87-A20-656-040		C-IC,MB81V4260S-60/70PFTN
	84-ZG1-695-040		C-IC,LH5V2RN1
	87-A20-975-040		C-IC,SN74LV74APW
	87-A20-974-040		C-IC,LC74781M-9017
	87-A20-918-040		C-IC,SM5878AM
TRANSISTOR			
	87-026-463-080		TR,2SA933S (0.3W)
	87-026-237-080		CHIP-TR,DTC124XK
	89-327-125-080		CHIP TR,2SC2712GR
	87-026-231-080		CHIP-TRANSISTER,DTA124XK
	87-A30-117-010		TR,2SA1357
	89-111-625-080		TR,2SA1162 (0.15W)
	87-026-580-080		C-TR,DTA123JK
	87-026-470-080		TR,HN1C03F (0.3W)
DIODE			
	87-020-027-080		CHIP-DIODE 1SS184
	87-017-024-040		C-DIODE,DA204K
	87-A40-180-040		C-DIODE,SB07-015C
	87-A40-384-080		C-ZENER,UDZ3.3B
3CD C.B			
C101	87-010-182-080		C-CAP,S 2200P-50 B
C102	87-016-669-080		C-CAP,S 0.1-25 K B
C103	87-016-669-080		C-CAP,S 0.1-25 K B
C104	87-016-669-080		C-CAP,S 0.1-25 K B
C105	87-010-404-040		CAP,E 4.7-50 SME
C106	87-016-369-080		C-CAP,S 0.033-25 B K
C107	87-010-197-080		CAP, CHIP 0.01 DM
C108	87-010-401-040		CAP,E 1-50 SME
C109	87-010-382-040		CAP,E 22-25 SME
C110	87-010-213-080		C-CAP,S 0.015-50 B
C111	87-010-263-040		CAP,E 100-10
C112	87-010-197-080		CAP, CHIP 0.01 DM
C113	87-016-369-080		C-CAP,S 0.033-25 B K
C114	87-016-369-080		C-CAP,S 0.033-25 B K
C115	87-016-369-080		C-CAP,S 0.033-25 B K
C116	87-012-158-080		C-CAP,S 390P-50 CH
C117	87-012-154-080		C-CAP,S 150P-50 CH
C118	87-010-494-040		CAP,E 1-50 GAS
C119	87-010-152-080		C-CAP,S 8P-50 CH
C120	87-010-992-080		C-CAP,S 0.047-25 B
C121	87-010-992-080		C-CAP,S 0.047-25 B
C123	87-016-669-080		C-CAP,S 0.1-25 K B
C125	87-010-198-080		CAP, CHIP 0.022
C126	87-016-669-080		C-CAP,S 0.1-25 K B
C127	87-010-555-040		CAP,E 100-10 GAS
C130	87-010-555-040		CAP,E 100-10 GAS
C131	87-010-555-040		CAP,E 100-10 GAS
C132	87-010-178-080		CHIP CAP 1000P
C133	87-010-555-040		CAP,E 100-10 GAS
C134	87-010-196-080		CHIP CAPACITOR,0.1-25
C135	87-010-196-080		CHIP CAPACITOR,0.1-25
C136	87-010-196-080		CHIP CAPACITOR,0.1-25
C137	87-010-196-080		CHIP CAPACITOR,0.1-25
C138	87-010-182-080		C-CAP,S 2200P-50 B
C139	87-010-197-080		CAP, CHIP 0.01 DM
C140	87-010-112-040		CAP,E 100-16
C141	87-010-196-080		CHIP CAPACITOR,0.1-25
C142	87-010-196-080		CHIP CAPACITOR,0.1-25
C143	87-010-213-080		C-CAP,S 0.015-50 B
C151	87-010-263-040		CAP,E 100-10
C152	87-010-197-080		CAP, CHIP 0.01 DM
C153	87-A10-893-040		CAP,E 220-10 M PW
C154	87-010-197-080		CAP, CHIP 0.01 DM
C155	87-010-184-080		CHIP CAPACITOR 3300P(K)
C156	87-010-992-080		C-CAP,S 0.047-25 B
C157	87-010-992-080		C-CAP,S 0.047-25 B
C158	87-012-156-080		C-CAP,S 220P-50 CH
C159	87-016-526-080		C-CAP,S 0.47-16 BK
C160	87-010-314-080		C-CAP,S 22P-50V
C161	87-010-182-080		C-CAP,S 2200P-50 B
C162	87-010-178-080		CHIP CAP 1000P
C201	87-016-669-080		C-CAP,S 0.1-25 K B
C204	87-010-197-080		CAP, CHIP 0.01 DM
C205	87-010-379-040		CAP,E 22-16 M SME
C206	87-010-322-080		C-CAP,S 100P-50 CH
C207	87-010-322-080		C-CAP,S 100P-50 CH
C208	87-010-322-080		C-CAP,S 100P-50 CH
C209	87-010-322-080		C-CAP,S 100P-50 CH
C210	87-016-669-080		C-CAP,S 0.1-25 K B
C211	87-010-263-040		CAP,E 100-10
C213	87-010-190-080		S CHIP F 0.01
C214	87-010-196-080		CHIP CAPACITOR,0.1-25
C301	87-016-251-040		CAP,E 220-16 SMG
C302	87-012-140-080		CAP 470P
C303	87-010-178-080		CHIP CAP 1000P
C304	87-010-384-040		CAP,E 100-25 SME
C305	87-010-982-040		CAP,E 33-25 GAS
C306	87-010-112-040		CAP,E 100-16
C307	87-010-196-080		CHIP CAPACITOR,0.1-25
C308	87-010-263-040		CAP,E 100-10
C309	87-010-196-080		CHIP CAPACITOR,0.1-25
C310	87-010-263-040		CAP,E 100-10
C311	87-010-196-080		CHIP CAPACITOR,0.1-25
C312	87-010-178-080		CHIP CAP 1000P
C320	87-010-196-080		CHIP CAPACITOR,0.1-25
C401	87-016-044-040		CAP,E 100-16 GAS
C402	87-010-190-080		S CHIP F 0.01
C403	87-010-190-080		S CHIP F 0.01
C501	87-010-197-080		CAP, CHIP 0.01 DM
C502	87-010-197-080		CAP, CHIP 0.01 DM
C503	87-010-197-080		CAP, CHIP 0.01 DM
C504	87-010-154-080		CAP CHIP 10P
C505	87-010-154-080		CAP CHIP 10P
C506	87-010-197-080		CAP, CHIP 0.01 DM
C508	87-010-263-040		CAP,E 100-10
C509	87-016-669-080		C-CAP,S 0.1-25 K B
C510	87-010-263-040		CAP,E 100-10
C511	87-016-669-080		C-CAP,S 0.1-25 K B
C512	87-010-197-080		CAP, CHIP 0.01 DM
C513	87-010-197-080		CAP, CHIP 0.01 DM
C514	87-010-197-080		CAP, CHIP 0.01 DM
C518	87-010-322-080		C-CAP,S 100P-50 CH
C519	87-012-145-080		CAP, CHIP S 270P CH
C520	87-012-157-080		C-CAP,S 330P-50 CH
C521	87-012-154-080		C-CAP,S 150P-50 CH
C522	87-010-371-080		CAP, ELECT 470-6.3V
C523	87-010-197-080		CAP, CHIP 0.01 DM
C524	87-010-197-080		CAP, CHIP 0.01 DM
C525	87-010-197-080		CAP, CHIP 0.01 DM
C526	87-010-197-080		CAP, CHIP 0.01 DM

REF. NO	PART NO.	KANRI NO.	DESCRIPTION
C527	87-010-197-080		CAP, CHIP 0.01 DM
C528	87-010-197-080		CAP, CHIP 0.01 DM
C529	87-010-197-080		CAP, CHIP 0.01 DM
C530	87-010-197-080		CAP, CHIP 0.01 DM
C531	87-010-197-080		CAP, CHIP 0.01 DM
C532	87-010-374-040		CAP,E 47-10
C533	87-010-197-080		CAP, CHIP 0.01 DM
C534	87-010-555-040		CAP,E 100-10 GAS
C535	87-010-197-080		CAP, CHIP 0.01 DM
C536	87-010-078-040		CAP,E 47-6.3 5L
C537	87-010-197-080		CAP, CHIP 0.01 DM
C538	87-010-196-080		CHIP CAPACITOR,0.1-25
C539	87-016-669-080		C-CAP,S 0.1-25 K B
C540	87-010-078-040		CAP,E 47-6.3 5L
C541	87-010-197-080		CAP, CHIP 0.01 DM
C542	87-010-318-080		C-CAP,S 47P-50 CH
C544	87-010-197-080		CAP, CHIP 0.01 DM
C546	87-010-197-080		CAP, CHIP 0.01 DM
C549	87-010-494-040		CAP,E 1-50 GAS
C550	87-010-196-080		CHIP CAPACITOR,0.1-25
C551	87-012-153-080		C-CAP,S 120P-50 CH
C552	87-016-526-080		C-CAP,S 0.47-16 BK
C554	87-010-197-080		CAP, CHIP 0.01 DM
C556	87-010-378-040		CAP,E 10-16
C557	87-010-316-080		C-CAP,S 33P-50 CH
C558	87-010-315-080		C-CAP,S 27P-50 CH
C560	87-010-197-080		CAP, CHIP 0.01 DM
C601	87-010-197-080		CAP, CHIP 0.01 DM
C602	87-010-197-080		CAP, CHIP 0.01 DM
C603	87-010-112-040		CAP,E 100-16
C604	87-010-196-080		CHIP CAPACITOR,0.1-25
C605	87-010-197-080		CAP, CHIP 0.01 DM
C606	87-010-197-080		CAP, CHIP 0.01 DM
C607	87-010-313-080		CAP, CHIP 18P
C608	87-010-313-080		CAP, CHIP 18P
C609	87-010-178-080		CHIP CAP 1000P
C610	87-010-178-080		CHIP CAP 1000P
C611	87-010-178-080		CHIP CAP 1000P
C612	87-010-178-080		CHIP CAP 1000P
C613	87-010-403-040		CAP,E 3.3-50 SME
C614	87-010-403-040		CAP,E 3.3-50 SME
C615	87-010-318-080		C-CAP,S 47P-50 CH
C616	87-010-318-080		C-CAP,S 47P-50 CH
CN101	87-A60-424-010		CONN,16P V TOC-B
CN102	87-099-199-010		CONN,6P 6216 H
CN401	87-099-212-010		CONN,5P 6216 V
CN403	87-099-030-010		CONN,13P 6216H
J501	87-009-502-010		JACK,PIN 1P Y EARTH
L101	87-005-196-080		COIL,10UH
L301	87-A50-095-010		COIL,68UH RCR875D
L302	87-005-426-080		COIL,3.3UH K FLR50
L502	87-005-204-080		COIL,47UH
L503	87-005-189-080		COIL 2.7UH
L504	87-005-187-080		COIL,1.8UH
L505	87-005-204-080		COIL,47UH
L506	87-005-204-080		COIL,47UH
L507	87-005-204-080		COIL,47UH
L508	87-005-817-080		C-COIL, 33UH J FLC32
M401	87-045-305-010		MOTOR, RF-500TB DC-5V (2MA)
R130	87-022-364-080		C-RES,S 82K-1/10W F
R131	87-022-364-080		C-RES,S 82K-1/10W F
R132	87-022-364-080		C-RES,S 82K-1/10W F
R133	87-022-364-080		C-RES,S 82K-1/10W F
R134	87-022-364-080		C-RES,S 82K-1/10W F
R135	87-022-364-080		C-RES,S 82K-1/10W F
R507	87-A00-408-080		C-RES,S 2K-1/10W D
S201	87-A90-162-010		SW,SL 1-1-3 SSSU
S401	87-036-109-010		PUSH SWITCH
S402	87-036-109-010		PUSH SWITCH
W1	84-ZG1-673-010		F-CABLE,5P 1.25 210MM BLACK N
W2	85-NFT-611-110		FF-CABLE 16P-1.0
W3	84-ZG1-630-010		CABLE FFC 6P-1.25
X201	87-A70-124-080		VIB,CER 8.0MHZ
X501	87-A70-125-080		VIB,XTAL 27MHZ 50PPM
X601	87-030-270-080		VIB,XTAL 16.9344MHZ
LED C.B			
LED401	87-070-200-080		LED,SLP636C-81-S-T1
LED402	87-017-350-080		LED,SEL1550CM
LED403	87-017-350-080		LED,SEL1550CM
LED404	87-070-200-080		LED,SLP636C-81-S-T1
T-T C.B			
C401	87-018-214-080		CAP TC U 0.1-50F
CON401	86-NFZ-675-010		CONN,5P H 6216-11H
PS401	87-026-573-010		IC,GP1S53V
DRIVE C.B			
CN3	87-009-349-010		CONN,6P H WHT PH
M20	87-045-358-010		MOT,RF-310TA 43
M21	87-045-356-010		MOT,RF-310TA 30
SW1	87-A90-042-010		SW,LEAF MSW-17310MVPO
CD MOTOR C.B			
CN4	87-099-210-010		CONN,5P H BLK 6216
M1	87-045-305-010		MOT,RF-500TB
SW1	87-035-110-010		SW,MICRO SPPB62
SW2	87-035-110-010		SW,MICRO SPPB62

- Regarding connectors, they are not stocked as they are not the initial order items.
  The connectors are available after they are supplied from connector manufacturers upon the order is received.

○ チップ抵抗部品コード / CHIP RESISTOR PART CODE

チップ抵抗部品コードの成り立ち
Chip Resistor Part Coding



チップ抵抗
Chip resistor

容量 Wattage	種類 Type	許容誤差 Tolerance	記号 Symbol	寸法 / Diamensions (mm)				抵抗コード　: A Resistor Code : A
				外形 / Form	L	W	t	
1/16W	1608	5%	CJ		1.6	0.8	0.45	108
1/10W	2125	5%	CJ		2	1.25	0.45	118
1/8W	3216	5%	CJ		3.2	1.6	0.55	128

TRANSISTOR ILLUSTRATION



2SA933S



2SA1162
2SC2712
DTA123JK
DTA124XK
DTC124XK



2SA1357



HN1C03F

BLOCK DIAGRAM




TO MAIN UNIT
TO ÐRIVE C.B
TO PICK UP ASSY
TO MAIN UNIT
CN403
CN102
CN101
CN301
CN402
IC505
IC201
IC401
IC202
IC102
S401
S402
S201 NTSC AUTO PAL PAL
J501 VIÐEO OUT
ÐIGITAL OUT (COAXIAL)
M101 (TRAY MOTOR)
TO T-T C.B
MAIN C.B VCÐ (CONÐUCTOR SIÐE)
LEÐ C.B
LEÐ401-404 (CÐ WINÐOW LIGHTING)
LEÐ 401
LEÐ 402
LEÐ 403
LEÐ 404
CON402



MAIN VCÐ C.B (COMPONENT SIÐE)


FROM
MAIN UNIT
FC4
5
1
T-T C.B
CON
401
4
2
5
3
1
PS401
R409
R408
C401
(RED)
(BLK)
M401
(TURN TABLE
MOTOR)
M
PICK UP ASSY
CON1
MAIN VCD C.B
CN101
DRIVE C.B
M20
(SPINDLE
MOTOR)
SW1
(INSIDE LIMIT
SW)
SW1
M21
(SLED
MOTOR)
PIN3
1
2
3
4
5
6
MAIN VCD C.B
CN102

SCHEMATIC DIAGRAM-1




MAIN VCD C.B (2/2)
FROM MAIN VCD C.B (1/2)
ÐACLK/16M
IC506 SN74LV74APW
1/2 FREQ. ÐIVIÐER
IC503 SN74LVU04APW
CLOCK OSC.
X501 27MHz
IC501 CL680-Ð1
MPEG-1 . VIÐEO&AUÐIO ÐECORÐER
IC504 MB81V4260S-60 /70PFTN Ð RAM
IC505 LH5V2RN1 ROM
IC507 LC74781M-9017
Q501-502 VIÐEO ÐRIVER
Q501 2SA1162GR
Q502 2SA1162GR
REG. Q601 2SC2712GR
IC601 SM5878AM
Ð/A CONV.
Q602 ÐTA123JK MUTE SW
Q603 HN1C03FB MUTE
D601 1SS184
VIÐEO OUT
TO/FROM MAIN VCÐ C.B (1/2)
TO/FROM MAIN VCÐ C.B (1/2)
OSÐÐATA
OSÐCLK
OSÐCS
R-CH
A-GNÐ
L-CH
SIGNAL
ANALOG AUÐIO (CÐ ÐATA)
ÐIGITAL AUÐIO
VIÐEO
CONTROL
WAVEFORM NO.

WAVE FORM

① IC101 Pin ㉝ (RF-O)
VOLT/DIV: 200mV
TIME/DIV: 0.5µS



EYE PATTERN
must be CLEAR and MAX

② IC501 Pin ㊽ DA XCK
16.93MHz
VOLT/DIV: 1V
TIME/DIV: 20nS



③ IC501 Pin ⑩⑦ GCK OUT
42.3MHz
VOLT/DIV: 1V
TIME/DIV: 10nS



④ IC503 Pin ⑧ 33 VCK
27MHz±1.35kHz
VOLT/DIV: 1V
TIME/DIV: 10nS



⑤ IC506 Pin ⑪ OSD CLK
13.5MHz±675Hz
VOLT/DIV: 1V
TIME/DIV: 20nS



⑥ IC504 Pin ㉚ $\overline{\text{UCAS}}$
(Pin ㉛ $\overline{\text{LCAS}}$)
VOLT/DIV: 1V
TIME/DIV: 2µS



⑦ IC501 Pin ㉝ $\overline{\text{VSync}}$
NTSC
VOLT/DIV: 1V
TIME/DIV: 5mS



⑧ IC501 Pin ㉝ $\overline{\text{VSync}}$
PAL
VOLT/DIV: 1V
TIME/DIV: 5mS



⑧ IC501 Pin ⑩① $\overline{\text{HSync}}$
PAL
VOLT/DIV: 1V
TIME/DIV: 20µS



IC501 Pin ⑩① $\overline{\text{HSync}}$
NTSC
VOLT/DIV: 1V
TIME/DIV: 20µS



IC DESCRIPTION

IC, CXA1992AR

Pin No.	Pin Name	I/O	Description
1	FEO	O	Output terminal for focus error amplifier. Internally connected to window comparator input for bias condition.
2	FEI	I	Input terminal for focus error.
3	FDFCT	I	Capacitor connection terminal for time constant used when there is defect.
4	FGD	I	This pin is connected to GND via capacitor when high frequency gain of the focus servo is attenuated.
5	FLB	I	This is a pin where the time constant is externally connected to raise the low frequency gain of the focus servo.
6	FE_O	O	Focus drive output.
7	FEM	I	Focus amplifier inverted input pin.
8	SRCH	I	This is a pin where the time constant is externally connected to generate the focus search waveform.
9	TGU	I	This is a pin where the selection time constant is externally connected to set the tracking servo the high frequency gain.
10	TG2	I	This is a pin where the selection time constant is externally connected to set the tracking high frequency gain.
11	FSET	I	Pin for setting peak of the phase compensator of the focus tracking.
12	TA_M	I	Tracking amplifier inverted input pin.
13	TA_O	O	Tracking drive output.
14	SL_P	I	Sled amplifier non-inverted input pin.
15	SL_M	I	Sled amplifier inverted input pin.
16	SL_O	O	Sled drive output.
17	ISET	I	The current which determines height of the focus search, track jump and sled kick is input with external resistance connected.
18	Vcc	I	Power supply.
19	LOCK	I	“L” setting starts sled disorder-prevention circuit. (Not pull-up resistance)
20	CLK	I	Clock input for serial data transfer from CPU. (No pull-up resistance)
21	XLT	I	Latch input from CPU. (No pull-up resistance)
22	DATA	I	Serial data input from CPU. (No pull-up resistance)
23	XRST	I	Reset system at “L” setting. (No pull-up resistance)
24	C_OUT	O	Signal output for track number counting.
25	SENS1	O	FZC, DFCT1, TZC, BALH, TGH, FOH, or ATSC is output depending on the command from CPU.
26	SENS2	O	DFCT2, MIRR, BALL, TGL or FOL is output depending on the command from CPU.
27	FOK	O	Output terminal for focus OK comparator.
28	CC2	I	Input pin where the DEFECT bottom hold output is capacitance coupled.
29	CC1	O	DEFECT bottom-hold output terminal. Internally connected to interruption comparator input.
30	CB	I	Connection terminal for DEFECT bottom-hold capacitor.
31	CP	I	Connection terminal for MIRR hold-capacitor. Anti-reverse input terminal for MIRR comparator.

Pin No.	Pin Name	I/O	Description
32	RF_I	I	Input terminal by capacity combination of RF summing amplifier.
33	RF_O	O	Output terminal of RF summing amplifier. Checkpoint of Eye pattern.
34	RF_M	I	Anti-reverse input terminal for RF summing amplifier. The gain of RF amplifier is decided by the connection resistance between RF_M and RFO terminals.
35	RFTC	I	This is a pin where the selection time constant is externally connected to control the RF level.
36	LD	O	APC amplifier output terminal.
37	PD	I	APC amplifier input terminal.
38, 39	PD1, PD2	I	RFI-V amplifier inverted input pin. These pins are connected to the A+C and B+C pins of the optical pickup, receiving by currents input.
40	FEBIAS	I/O	Bias adjustment pin of the focus error amplifier.
41, 42	F, E	I	F and EIV amplifier inverted input pins. These pins are connected to the F and E of the optical pickup, receiving by current input.
43	EI	—	Gain adjustment pin of the I-V amplifier E. (When not in use of BAL automatic adjustment)
44	VEE	—	GND connection pin.
45	TEO	O	Output terminal for tacking-error amplifier. Output E-F signal.
46	LPFI	I	BAL adjustment comparator input pin. (Input through LPF from TEO)
47	TEI	I	Input terminal for tracking error.
48	ATSC	I	Window-comparator input terminal for detecting ATSC.
49	TZC	I	Input terminal for tracking-zero cross comparator.
50	TDFCT	I	Capacitor connection pin for the time constant used when there is defect.
51	VC	O	Output terminal for DC voltage reduced to half of VCC+VEE.
52	FZC	I	Input terminal for focus-zero cross comparator.

IC, CXD2540Q

Pin No.	Pin Name	I/O	Description
1	FOK	I	Focus OK input. Used for SENS output and the servo auto sequencer.
2	FSW	O	Spindle motor output filter switching output.
3	MON	O	Spindle motor on/off control output.
4	MDP	O	Spindle motor servo control.
5	MDS	O	
6	LOCK	O	High, when sampled value of GFS at 460Hz is high. Low, when sampled value of GFS at 460Hz is low by 8 times successively.
7	NC		
8	VCOO	O	Analog EFM PLL oscillation circuit output.
9	VCOI	I	Analog EFM PLL oscillation circuit input. fLOCK=8.6436MHz.
10	TEST	I	TEST pin.
11	PDO	O	Analog EFM PLL charge pump output.
12	VSS		GND.
13	PWMI	I	Spindle motor external control input.
14	V16M	O	VCO2 oscillation output for the wide-band EFM PLL.
15	VCTL	I	VCO2 control voltage input for the wide-band EFM PLL.
16	VPCO	O	Wide-band EFM PLL charge pump output.
17	VCKI	I	VCO2 oscillation input for the wide-band EFM PLL.
18	FILO	O	Multiplier PLL (slave=digital PLL) filter output.
19	FILI	I	Multiplier PLL filter input.
20	PCO	O	Multiplier PLL charge pump output.
21	AVSS		Analog GND.
22	CLTV	I	Multiplier VCO1 control voltage input.
23	AVDD		Analog power supply (5V).
24	RF	I	EFM signal input.
25	BIAS	I	Constant current input of the asymmetry circuit.
26	ASYI	I	Asymmetry comparator voltage input.
27	ASYO	O	EFM full-swing output.
28	ASYE	I	Low: asymmetry circuit off; high: asymmetry circuit on.
29	NC		
30	PSSL	I	Audio data output mode switching input. Low: serial output; high: parallel output.
31	WDCK	O	D/A interface for 48-bit slot. Word clock f=2Fs.
32	LRCK	O	D/A interface for 48-bit slot. LR clock f=Fs.
33	VDD		Power supply (5V).
34	DA16	O	DA16 (MSB) output when PSSL=1. 48-bit slot serial data (two's complement, MSB first) when PSSL=0.
35	DA15	O	DA15 output when PSSL=1. 48-bit slot bit clock when PSSL=0.
36	DA14	O	DA14 output when PSSL=1. 64-bit slot serial data (two's complement, LSB first) when PSSL=0.
37	DA13	O	DA13 output when PSSL=1. 64-bit slot bit clock when PSSL=0.
38	DA12	O	DA12 output when PSSL=1. 64-bit slot LR clock when PSSL=0.

Pin No.	Pin Name	I/O	Description
39	DA11	O	DA11 output when PSSL=1. GTOP output when PSSL=0.
40	DA10	O	DA10 output when PSSL=1. XUGF output when PSSL=0.
41	DA09	O	DA09 output when PSSL=1. XPLCK output when PSSL=0.
42	DA08	O	DA08 output when PSSL=1. GFS output when PSSL=0.
43	DA07	O	DA07 output when PSSL=1. RFCK output when PSSL=0.
44	DA06	O	DA06 output when PSSL=1. C2PO output when PSSL=0.
45	DA05	O	DA05 output when PSSL=1. XRAOF output when PSSL=0.
46	DA04	O	DA04 output when PSSL=1. MNT3 output when PSSL=0.
47	DA03	O	DA03 output when PSSL=1. MNT2 output when PSSL=0.
48	DA02	O	DA02 output when PSSL=1. MNT1 output when PSSL=0.
49	DA01	O	DA01 output when PSSL=1. MNT0 output when PSSL=0.
50	APTR	O	Aperture compensation control output. This pin outputs a high signal when the right channel is used.
51	APTL	O	Aperture compensation control output. This pin outputs a high signal when the left channel is used.
52	VSS		GND.
53	XTAI	I	Crystal oscillation circuit input.
54	XTAO	O	Crystal oscillation circuit output.
55	XTSL	I	Crystal selector input.
56	FSTT	O	2/3 frequency divider output for Pins 53 and 54.
57	FSOF	O	1/4 frequency divider output for Pins 53 and 54.
58	C16M	O	16.9344MHz output. (V16M output in CLV-W and CAV-W modes)
59	MD2	I	Digital-out on/off control. High: on; low: off
60	DOUT	O	Digital-out output.
61	EMPH	O	Outputs a high signal when the playback disc has emphasis, and a low signal when there is no emphasis.
62	WFCK	I	WFCK (write frame clock) output.
63	SCOR	O	Outputs a high signal when either subcode sync S0 or S1 is detected.
64	SBSO	O	Sub P to W serial output.
65	EXCK	I	SBSO readout clock input.
66	SQSO	O	Sub Q 80-bit and PCM peak, level metter and internal status outputs.
67	SQCK	I	SQSO readout clock input.
68	MUTE	I	High: mute; low: release
69	SENS	—	SENS output to CPU.
70	XRST	I	System reset. Reset when low.
71	DATA	O	Serial data input from CPU.
72	XLAT	O	Latch input from CPU. Serial data is latched at the falling edge.
73	VDD		Power supply (5V).
74	CLOK	O	Serial data transfer clock input from CPU.
75	SEIN	I	SENS input from SSP.
76	CNIN	I	Track jump count signal input.

Pin No.	Pin Name	I/O	Description
77	DATO	O	Serial data output to SSP.
78	XLTO	O	Serial data latch output to SSP. Latched at the falling edge.
79	CLKO	O	Serial data transfer clock output to SSP.
80	MIRR	I	Mirror signal input. Used when the number of tracks is 128 or more for the 2N-track jump and M track move of the auto sequencer.

Notes)

- The 64-bit slot is an LSB first, two's complement output, and the 48-bit slot is an MSB first, two's complement output.
- GTOP is used to monitor the frame sync protection status. (High: sync protection window open.)
- XUGF is the negative pulse for the frame sync obtained from the EFM signal. It is the signal before sync protection.
- XPLCK is the inverse of the EFM PLL clock. The PLL is designed so that the falling edge and the EFM signal transition point coincide.
- GFS goes high when the frame sync and the insertion protection timing match.
- RFCK is derived from the crystal accuracy, and has a cycle of 136μ.
- C2PO represents the data error status.
- XRAOF is generated when the 32K RAM exceeds the ±28F jitter margin.

IC, CL680

Pin No.	Pin Name	I/O	Description
1	NC	—	No connection.
2	VSS	—	GND.
3	CD BCK	I	Bit clock input from CD DSP.
4	CD DATA	I	Data input from CD DSP.
5	CD LRCK	I	LRCK input from CD DSP.
6	CD C2PO	I	C2 pointer input from CD DSP.
7-9	NC	—	No connection.
10-15	MD0-MD5	I/O	DRAM/ROM interface. (DATA)
16	VSS	—	Ground.
17	MD6	I/O	DRAM/ROM interface. (DATA)
18	VDD3	—	Power supply 3.3V.
19	MD7	I/O	DRAM/ROM interface. (DATA)
20	VSS	—	Ground.
21	MD8	I/O	DRAM/ROM interface. (DATA)
22	VDD3	—	Power supply 3.3V.
23-29	MD9-MD15	I/O	DRAM/ROM interface. (DATA)
30-36	NC	—	No connection.
37	$\overline{\text{MCE}}$	—	ROM chip enable.
38	$\overline{\text{MWE}}$	O	DRAM write enable.
39	VSS	—	Ground.
40	$\overline{\text{CAS}}$	O	DRAM/ROM interface.
41	VDD3	—	Power supply 3.3V.
42	$\overline{\text{RASO}}$	O	DRAM/ROM interface.
43	$\overline{\text{RASI}}$	O	
44-46	MA10-MA8	O	DRAM/ROM interface. (Address)
47	VSS	—	Ground.
48	MA7	O	DRAM/ROM interface. (Address)
49	VDD3	—	Power supply 3.3V.
50-52	MA6-MA4	O	DRAM/ROM interface. (Address)
53	VSS	—	Ground.
54	MA3	O	DRAM/ROM interface. (Address)
55	VDD3	—	Power supply 3.3V.
56-58	MA2-MA0	O	DRAM/ROM interface. (Address)
59	PGIO7	I/O	Programmable I/O.
60	$\overline{\text{RESET}}$	I	Reset input.
61	VDD MAX IN	—	Power supply - VDDMAX. (5.0V)
62-64	NC	—	No connection.
65	AGND DAC	—	Analog ground.
66	A DAC	—	Analog power supply (DAC) : 3.3V.
67	COMP OUT	O	Composite out.
68	AGND DAC	—	Analog ground.

Pin No.	Pin Name	I/O	Description
69	Y OUT	O	Video signal “Y” OUT.
70	AVDD DAC	—	Analog power supply (DAC) 3.3V.
71	AGND DAC	—	Analog ground.
72	R REF	I	Reference resistor input.
73	V REF	I	Voltage reference input.
74	AVDD DAC	—	Analog power supply (DAC) : 3.3V.
75	C OUT	O	Video signal “C” out.
76	AGND DAC	—	Analog ground.
77-79	CLK SEL0-2	I	Clock selection input.
80	VSS	—	Ground.
81	CLK SEL3	I	Clock selection input.
82	VDD3	—	Power supply 3.3V.
83, 84	CLK SEL4, 5	I	Clock selection input.
85	AGND PLL	—	Analog ground.
86	DA XCK	I	DA XCK (16.933MHz) input.
87	AVDD PLL	—	Analog power supply 3.3V.
88	DA EMP	O	DAC-emphasis output.
89, 90	PGIO5, O6	I/O	Programmable I/O.
91	PGIO0	I/O	
92	PGIO8	I/O	
93	$\overline{\text{VSYNC}}/\overline{\text{CSYNC}}$	O	$\overline{\text{VSYNC}}/\overline{\text{CSYNC}}$ output.
94	AVDD PLL	—	Analog power supply (PLL) 3.3V.
95	VID_DAC_CK	O	Video DAC clock.
96	PROC_CK	O	Processor clock.
97	AUD_XCK	O	Audio XCK.
98	AGND PLL	—	Analog ground.
99	VSS	—	Ground.
100	NC	—	No connection.
101	$\overline{\text{HSYNC}}$	O	$\overline{\text{HSYNC}}$ output.
102	VDD3	—	Power supply 3.3V.
103	VCK OUT	O	VCK out.
104	VSS	—	Ground.
105	GCK	I	Global clock signal input. (42.3MHz)
106	VCK	I	Video clock signal input. (27.0MHz)
107	GCK OUT	O	Global clock signal output. (27.0MHz)
108	DA LRCK	O	DAC-LRCK output.
109	VDD MAX OUT	—	Power supply (VDD MAX) : 5.0V.
110	DA DATA	O	DAC-PCM data output.
111	DA BCK	O	DAC-BIT clock output.
112	HD OUT	O	Micon interface. (Data out)
113	HRDY	O	Micon interface. (Host ready)

Pin No.	Pin Name	I/O	Description
114	$\overline{\text{HINT}}$	O	Micon interface. (Host interrupt)
115	CDG SCK	I	CD-G serial clock input.
116	VSS	—	Ground.
117	HCK	I	Micon interface. (Host clock)
118	VDD3	—	Power supply 3.3V.
119	HD IN	I	Micon interface. (Host data in)
120	VDD3	—	Power supply 3.3V.
121	HSEL	I	Micon interface. (Host select in)
122	CDG DATA	I	CD-G data input.
123	CDG VFSY	I	CD-G VFSY input.
124	CDG SOSI	I	CD-G SOSI input.
125	DSP-XCK	O	DSP-XCK output.
126-128	NC	—	No connection.

IC, LC74781M

Pin No.	Pin Name	I/O	Description
1	VSS1	—	GND connection terminal. (Digital ground terminal).
2	Xtal IN	I	External X'tal and capacitor for internal sync generator, or the external clock are connected to this terminal. (2fsc or 4fsc).
3	Xtal OUT	O	
4	CTRL1	I	Either the external clock input mode or the X'tal generator mode is selected by this selector terminal. L: X'tal generator mode, H: External clock input.
5	BLANK	O	Blank signal (character and the green ORed signal) is output from this terminal. (MODE 0: composite sync signal is output at H.) When reset ($\overline{RST}$ terminal = L), the X'tal clock signal is output. (It is not output when reset by the reset command).
6	OSC IN	I	External coil and capacitor for the character output dot clock generator are connected to this terminal.
7	OSC OUT	O	
8	CHARA	O	The character signal is output from this terminal. (MOD 0: when H, the external sync signal identification signal is output from this terminal. This output signal tells whether the external sync signal is present or not. When external sync signal is present, H is output.) When reset ($\overline{RST}$ terminal = L), the dot clock signal (LC oscillator) is output. (It is not output when reset by the reset command).
9	$\overline{CS}$	I	Enable signal for the serial data input is input to this terminal. The serial data input is enabled at L. Pull-up resistor is built-in. (Hysteresis input).
10	SCLK	I	Clock of the serial data input is input to this terminal. Pull-up resistor is built-in. (Hysteresis input).
11	SIN	I	Serial data input terminal. Pull-up resistor is built-in. (Hysteresis input).
12	VDD2	—	Power supply for the composite video signal level adjustment. (Analog power supply).
13	CV OUT	O	Composite video signal output terminal.
14	NC	—	Connected to GND or not connected.
15	CV IN	I	Composite video signal input terminal.
16	VDD1	—	Power supply (+5V digital power supply).
17	SYN IN	I	Video signal for the internal sync separator circuit is input to this terminal. (When the internal sync separator circuit is not used, the horizontal sync signal or composite sync signal is input to this terminal).
18	SEP C	—	Internal sync separator circuit bias voltage monitoring terminal.
19	SEP OUT	O	The composite sync output signal of the internal sync separator circuit is output from this terminal. (H: MOD 1. H: during internal sync mode. L: during external sync mode.) (When internal sync separator circuit is not used, the SYN IN input signal is output from this terminal).
20	SEP IN	I	The output signal of the SEP OUT terminal is integrated so that the vertical sync signal is input to this terminal. An integrator circuit must be connected between the SEP OUT terminal and this terminal. When this terminal is not used, it must be connected to VDD1.
21	CTRL2	I	When selecting any of the NTSC or PAL or PAL-M or PAL-N system, the pin setting has priority. When L, the NTSC system is selected after resetting. Selection of either NTSC or PAL or PAL-M or PAL-N system by the command becomes effective. H: PAL-M system.

Pin No.	Pin Name	I/O	Description
22	CTRL3	I	Controls whether or not to input the $\overline{\text{VSYNC}}$ signal to the SEPIN input. L: to input the $\overline{\text{VSYNC}}$ signal. H: not to input the $\overline{\text{VSYNC}}$ signal.
23	$\overline{\text{RST}}$	I	System reset input terminal. Pull-up resistor is built-in. (Hysteresis input).
24	VDD1	—	Power supply. (+5V digital power supply).

IC, µPD78016FGC

Pin No.	Pin Name	I/O	Description
1	RBPLS	O	RADIAL BALANCE PLUS.
2	AMUTE	O	AUDIO ANALOG MUTE (H=MUTE ON).
3	GFS	I	GFS.
4	XVCDMD	I	AUDIO/VIDEO CD MODE (L=VCD=SPINDLE GAIN UP).
5	MD2	O	DOUT MUTE CONT.
6	EMPH	I	EMPHASIS.
7	SQSO	I	SQDATA FROM CD.
8	SQCK	O	SQCLK TO CD.
9	VSS	—	GND.
10	SWNT	I	SW TV OUT MODE (L=NTSC).
11	SWAUTO	I	SW TV OUT MODE (L=NTSC/PAL AUTO).
12	SWPAL	I	SW TV OUT MODE (L=PAL).
13	EMERG	I	POWER EMERGENCY STOP (L*3sec=STOP).
14	NC	—	Nou used.
15	LPCSEL	I	“LPC ON/OFF (H=ON, NORMAL)”.
16	NC	—	Nou used.
17	LOCK	O	GFS (FRAME SYNC) LOCK (NO USE=H).
18	DMUTE	O	DIGITAL DATA OUT MUTE.
19	SENS	I	DSP SENS1 FROM CD.
20	XCDRST	O	CD RESET.
21	DATA	O	DATA TO CD.
22	XLAT	O	XLT TO CD.
23	CLOK	O	CLK TO CD.
24	VSS	—	GND.
25	FOK	I	FOCUS OK.
26	SENS2	I	SSP SENS2 FROM CD.
27	XBUSY	I/O	READY/BUSY I/O TO HOST OD.
28	NC	—	Nou used.
29	NC	—	
30	NC	—	
31	TST0	I/O	CHECK LAND.
32	TST1	I/O	
33	TST2	I/O	
34	TST3	I/O	
35	RESET	I	RESET.
36	HRDY	I	HRDY FROM CL680.
37	XHINT	I	HINT FROM CL680.
38	NC	—	Nou used.
39	SCOR	I	SCOR FROM CD.
40	VDD	—	5.0VDD.
41	XO	O	8.0MHz CERALOCK.

Pin No.	Pin Name	I/O	Description
42	XI	I	8.0MHz CERALOCK.
43	VSS	—	GND.
44	XT2	—	Nou used.
45	XT1	I	5.0VDD.
46	AVSS	—	GND.
47	XMPGRST	O	MPEG BLOCK IC RESET.
48	HSEL	O	ADDRESS/DATA SEL TO CL680.
49	INLSW	I	INSIDE LIMIT SW.
50	NC	—	Nou used.
51	OSDXCS	O	OSD CHIP SELECT.
52	ABSEL	I	CXA1992A/B SELECT (L=CXA1992A).
53	CLVSEL	I	CLV MODE SELECT (H=CLV-N).
54	AADSEL	I	AUTO ADJUST SELECT (H=AUTO ON).
55	AVDD	—	5.0VDD.
56	AVREF	—	
57	HDOUT	I	HD-OUT FROM CL680.
58	HDIN	O	HD-IN TO CL680.
59	HCK	O	HCK TO CL680.
60	OSDDATA	O	OSD DATA.
61	OSDCLK	O	OSD CLOCK.
62	COMMAND	I	COMMAND FROM HOST.
63	STATUS	O	STATUS TO HOST.
64	SCK	I	SCK FROM HOST.

IC, SM5878M

Pin No.	Pin Name	I/O	Description
1	MUTE	I	MODE = H: Soft mute ON/OFF terminal. (Mute at H). MODE = L: Attenuator level DOWN/UP terminal. (DOWN at H).
2	DEEM	I	De-emphasis ON/OFF terminal. (De-emphasis ON at H).
3	CKO	O	Oscillator clock output. (16.9344 MHz).
4	DVSS	—	Digital VSS terminal.
5	BCKI	I	Bit clock input terminal.
6	DI	I	Serial data input terminal.
7	DVDD	—	Digital VDD terminal.
8	LRCI	I	Sample rate clock (fs) input terminal. (H = L ch/L = R ch).
9	TSTN	I	Test input. (“H” or open during normal operation)
10	TO1	O	Test output 1. (Normally low level output).
11	AVDDL	—	Analog VDD terminal. (For L ch).
12	LO	O	Left channel analog output terminal.
13	AVSS	—	Analog VSS terminal.
14	RO	O	Right channel analog output terminal.
15	AVDDR	—	Analog VDD terminal. (For R ch).
16	MUTEO	O	Infinity zero detection output.
17	XVDD	—	X’tal system VDD terminal.
18	XTI	I	X’tal oscillator terminal. (Or external clock input terminal of 16.9344 MHz).
19	XTO	O	X’tal oscillator terminal.
20	XVSS	—	X’tal system VSS terminal.
21	DS	I	Double-speed/normal playback selection. (Double-speed at H).
22	RSTN	I	Reset terminal. (Reset at L).
23	MODE	I	Soft mute/Attenuator mode selection. (Soft mute at H).
24	ATCK	I	Attenuator level setup clock (Ignored when MODE = H).

IC BLOCK DIAGRAM

IC, BA5915FP



T.S.D: Thermal shut-down
Resistors are in units of Ω.

IC, M5291FP



IC, LB1644



TRUH TABLE

IN1	IN2	OUT1	OUT2	IN3	IN4	OUT3	OUT4
0	0	L	L	0	0	L	L
1	0	H	L	1	0	H	L
0	1	L	H	0	1	L	H
1	1	L	L	1	1	L	L

INPUT			OUTPUT				MODE	
IN1	IN2.3	IN4	OUT1	OUT2	OUT3	OUT4	M1	M2
0	0	0	L	L	L	L	BRAKE	BRAKE
1	0	0	H	L	L	L	FF/REW	BRAKE
0	1	1	L	H	L	L	REW/FF	BRAKE
1	1	0	L	L	H	L	BRAKE	FF/REW
0	0	1	L	L	L	H	BRAKE	REW/FF
1	1	1	L	L	L	L	BRAKE	BRAKE

TEST MODE

1. How to Activate CD Test Mode
   Insert the AC plug while pressing the function CD button.
   All FL display tubes will light up, and the test mode will be activated.

2. How to Cancel CD Test Mode
   Either one of the following operations will cancel the CD test mode.
   - Press the function button. (except CD function button)
   - Press the power switch button.
   - Disconnect the AC plug

3. CD Test Mode Functions
   When test mode is activated, the following mode functions from No.1 to No.5 can be used by pressing the operation keys.

Mode/No.	Operation	FL display	Operation	Contents
Start mode No.1	Activation	TEST□□ □□ □□ Flashes repeatdly	• Test mode is activated. • CD block power is ON.	• Test mode
Search mode No.2	■ key		• Continual focus search (The pickup lens repeats the full-swing up-down motion.) * Avoid continual searches that last for more than 10 minutes. * NOTE 1	FOCUS SERVO • Check focus search waveform • Check focus error waveform (FOK/FZC are not monitored in the search mode)
Play mode No.3	◀▶key		• Normal playback • Focus search is continued if TOC cannot be read. * NOTE 1	FOCUS SERVO/TRACKING SERVO CLV SERVO/SLED SERVO Check FOK/FZC
Traverse mode No.4	⏸ key		• During normal disc playback Press once; tracking servo OFF Press twice; tracking servo ON * NOTE 2	TRACKING SERVO ON/OFF Tracking balance (traverse) check
Sled mode No.5	⏮key ⏭	All lamps light	• Pickup moves to the outermost track • Pickup moves to the innermost track * NOTE 3 (During playback, machine operates normally.)	SLED SERVO Check SLED mechanism operation

* NOTE 1: There are cases when the tracking servo cannot be locked owing to the protection circuit being operated when heat builds up in the driver IC if the focus search is operated continually for more than 10 minutes. In these cases the power supply should be switched off for 10 minutes until heat has been reduced and then re-started.
* NOTE 2: Do not press the ⏮ or ⏭ keys when the machine is in the ⏸ status is active. If they are pressed, playback will not be possible after the ⏸ status has been canceled. If the ⏮ or ⏭ keys are pressed in the ⏸ status, press the ■ key and return to the start mode (No.1).
* NOTE 3: When pressing the ⏮ or ⏭ keys, take care to avoid damage to the gears. Because the sled motor is activated when the ⏮ or ⏭ keys are pressed, even when the pick-up is at the outermost or innermost track.

4. Operation Outline
   The operation of each mode is carried out in the direction of the arrows from the start mode as indicated in the following illustration.



   If the DISC DIRECT PLAY button is pressed, the machine performs the same operation as the PLAY button is pressed as shown. If the tray is opened by pressing OPEN/CLOSE button during Play mode or Traverse mode, the machine returns to the Start mode.

5. How to check the Automatic Adjustment Values
   The automatic adjustment values can be checked by pressing the square (■) button.
   FL display (displayed in hexadecimal values)



Note) The reference value is “20 08 08”.

MECHANICAL EXPLODED VIEW 1/1



MECHANICAL PARTS LIST 1/1

DESCRIPTIONで判断できない物は "REFERENCE NAME LIST" を参照してください。
If can't understand for Description please kindly refer to "REFERENCE NAME LIST".

REF. NO	PART NO.	KANRI NO.	DESCRIPTION
1	84-ZG1-239-210		PULLY,WORM N
2	84-ZG1-267-010		PULLEY,LOAD MO 8
3	81-ZG1-239-010		S-SCREW,TT
4	81-ZG1-291-110		GEAR,TRAY RELAY NO3
5	81-ZG1-271-010		S-SCREW MECH REAR
6	81-ZG1-277-310		HLDR,MAGNET N
7	81-ZG1-255-110		PLATE,MAGNET MK2
8	83-ZG3-213-010		LVR,SW
9	84-ZG1-003-310		TRAY,NO2-B
10	87-045-364-010		MOTOR(BCH3B14)
11	84-ZG1-005-210		TURNTABLE,NO1(*)
12	84-ZG1-011-010		REFLECTOR,CD
13	84-ZG1-259-010		SPR-P,WORM
14	84-ZG1-208-210		LEVER,CAM
15	84-ZG1-209-010		BELT,SQ1.8-117.7
16	84-ZG1-211-010		SPR-E CAM S
17	84-ZG1-215-410		GEAR,MAIN CAM BLU
18	84-ZG1-216-310		SLIDE,MECHA CAM YEL
19	84-ZG1-205-110		GEAR,TRAY
20	84-ZG1-206-110		GEAR,RELAY
21	84-ZG1-207-010		PULLEY,RELAY
22	84-ZG1-221-010		GEAR,MAIN TT
23	84-ZG1-238-010		GEAR,WORM N
24	84-ZG1-224-010		LEVER,TT
25	84-ZG1-225-010		BELT,SQ1.0-63.3
26	83-ZG3-602-010		RING,MAG
27	87-045-305-010		MOTOR, RF-500TB DC-5V (2MA)
28	84-ZG1-248-010		SPR-C,WORM
A	87-067-703-010		TAPPING SCREW, BVT2+3-10
B	87-251-070-410		U+2.6-3
C	87-342-036-210		UT2+2-8
D	87-067-981-010		BVT2+3-6 BLK

CD MECHANISM EXPLODED VIEW 1/1 (3ZG-2 E1)



CD MECHANISM PARTS LIST 1/1 (3ZG-2 E1)

DESCRIPTIONで判断できない物は "REFERENCE NAME LIST" を参照してください。
If can't understand for Description please kindly refer to "REFERENCE NAME LIST".

REF. NO	PART NO.	KANRI NO.	DESCRIPTION
1	83-ZG2-243-110		CHAS ASSY,SHT
2	83-ZG2-235-010		GEAR,A3
3	83-ZG2-205-210		GEAR,B
4	83-ZG2-236-010		GEAR MOTOR 3
5	83-ZG2-240-010		SHAFT,SLIDE 3
6	87-A90-836-010		PICKUP,KSS-213F
8	83-ZG2-233-010		TURN TABLE,A5
11	83-ZG2-245-110		LEVER,SHUTTER
12	83-ZG2-250-010		SPR-E,SHT 2
A	87-261-032-210		SCREW V+2-3

CX-NAK572
CX-NK270
CX-NK290
CX-NK370
CX-NK570
CX-NK765
CX-NK770
CX-NK970
DX-SNKH100

REFERENCE NAME LIST

ELECTRICAL SECTION

DESCRIPTION	REFERENCE NAME
ANT	ANTENNAS
C-	CHIP
C-CAP	CAP, CHIP
C-CAP TN	CAP, CHIP TANTALUM
C-COIL	COIL, CHIP
C-DI	DIODE, CHIP
C-DIODE	DIODE, CHIP
C-FET	FET, CHIP
C-FOTR	FILTER, CHIP
C-JACK	JACK, CHIP
C-LED	LED, CHIP
C-RES	RES, CHIP
C-SFR	SFR, CHIP
C-SLIDE SW	SLIDE SWITCH, CHIP
C-SW	SWITCH, CHIP
C-TR	TRANSISTOR, CHIP
C-VR	VOLUME, CHIP
C-ZENER	ZENER, CHIP
CAP, CER	CAP, CERA-SOL
CAP, E	CAP, ELECT
CAP, M/F	CAP, FILM
CAP, TC	CAP, CERA-SOL
CAP, TC-U	CAP, CERA-SOL SS
CAP, TN	CAP, TANTALUM
CERA FIL	FILTER, CERAMIC
CF	FILTER, CERAMIC
DL	DELAY LINE
E/CAP	CAP, ELECT
FILT	FILTER
FLTR	FILTER
FUSE RES	RES, FUSE
MOT	MOTOR
P-DIODE	PHOTO DIODE
P-SNSR	PHOTO SENSER
P-TR	PHOTO TRANSISTOR
POLY VARI	VARIABLE CAPACITOR
PPCAP	CAP, PP
PT	POWER TRANSFORMER
PTR, RES	PTR, MELF
RC	REMOTE CONTROLLER
RES NF	RES, NON-FLAMMABLE
RESO	RESONATOR
SHLD	SHIELD
SOL	SOLENOID
SPKR	SPEAKER
SW, LVR	SWITCH, LEVER
SW, RTRY	SWITCH, ROTARY
SW, SL	SWITCH, SLIDE
TC CAP	CAP, CERA-SOL
THMS	THERMISTOR
TR	TRANSISTOR
TRIMMER	CAP, TRIMMER
TUN-CAP	VARIABLE CAPACITOR
VIB, CER	RESONATOR, CERAMIC
VIB, XTAL	RESONATOR, CRYSTAL
VR	VOLUME
ZENER	DIODE, ZENER

MECHANICAL SECTION

DESCRIPTION	REFERENCE NAME
ADHESHIVE	SHEET ADHESHIVE
AZ	AZIMUTH
BAR-ANT	BAR-ANTENNA
BAT	BATTERY
BATT	BATTERY
BRG	BEARING
BTN	BUTTON
CAB	CABINET
CASS	CASSETTE
CHAS	CHASSIS
CLR	COLLAR
CONT	CONTROL
CRSR	CURSOR
CU	CUSHION
CUSH	CUSHION
DIR	DIRECTION
DUBB	DUBBING
FL	FRONT LOADING
FLY-WHL	FLYWHEEL
FR	FRONT
FUN	FUNCTION
G-CU	G-CUSHION
HDL	HANDOL
HIMERON	CLOTH
HINGE, BAT	HINGE, BATTERY
HLDR	HOLDER
HT-SINK	HEAT SINK
IB	INSTRUCTION BOOKLET
IDLE	IDLER
IND, L-R	INDICATOR, L-R
KEY, CONT	KEY, CONTROL
KEY, PRGM	KEY, PROGRAM
KNOB, SL	KNOB, SLIDE
LBL	LABEL
LID, BATT	LID, BATTERY
LID, CASS	LID, CASSETTE
LVR	LEVER
P-SP	P-SPRING
PANEL, CONT	PANEL, CONTROL
PANEL, FR	PANEL, FRONT
PRGM	PROGRAM
PULLY, LOAD MO	PULLY, LOAD MOTOR
RBN	RIBBON
S-	SPECIAL
SEG	SEGMENT
SH	SHEET
SHLD-SH	SHIELD-SHEET
SL	SLIDE
SP	SPRING
SP-SCREW	SPECIAL-SCREW
SPACER, BAT	SPACER, BATTERY
SPR	SPRING
SPR-P	P-SPRING
SPR-PC-PUSH	P-SPRING, C-PUSH
T-SP	T-SPRING
TERM	TERMINAL
TRIG	TRIGGER
TUN	TUNING
VOL	VOLUME
W	WASHER
WHL	WHEEL
WORM-WHL	WORM-WHEEL

サービス技術ニュース	
番号	連絡内容
G一　一	
G一　一	
G一　一	

アイワ株式会社
AIWA CO.,LTD.

〒110　東京都台東区池之端1-2-11　☎03（3827）3111（代表）

912162

Tokyo Japan

Printed in Singpore